

Installation / Operation

Applies to: **Model UDBP**

and **Model UDBS**

**V3® Series High Static
Blower-Type Unit Heaters**



⚠ WARNING:

FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings exactly could result in serious injury, death, or property damage.

Be sure to read and understand the installation, operation, and service instructions in this manual.

Improper installation, adjustment, alteration, service, or maintenance can cause serious injury, death, or property damage.

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- **WHAT TO DO IF YOU SMELL GAS**
 - Do not try to light any appliance.
 - Do not touch any electrical switch; do not use any phone in your building.
 - Leave the building immediately.
 - Immediately call your gas supplier from a phone remote from the building. Follow the gas supplier's instructions.
 - If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency, or the gas supplier.

Table of Contents

| | | | |
|--|-------|--|-------|
| 1.0 General | 2-4 | 6.4 Blowers, Belts, and Drives | 18 |
| 1.1 Hazard Labels and Notices..... | 2 | 7.0 Electrical Supply and Wiring | 20-27 |
| 1.2 General Installation Information | 3 | 7.1 General..... | 20 |
| 1.3 Warranty..... | 3 | 7.2 Supply Wiring | 20 |
| 1.4 Installation Codes | 3 | 7.3 24V Control Wiring Connections | 21 |
| 2.0 Unit Heater Location..... | 4-6 | 7.4 Wiring Diagrams..... | 22 |
| 2.1 Heater Throw | 4 | 7.5 Electrical Operating Components | 26 |
| 2.2 Heater Sound Data | 5 | 8.0 Controls and Operation..... | 27-31 |
| 2.3 Location Recommendations | 6 | 8.1 Thermostat..... | 27 |
| 3.0 Uncrating and Preparation..... | 7-8 | 8.2 DDC Controls, Options D10 and D14..... | 28 |
| 3.1 Uncrating and Inspecting | 7 | 8.3 Ignition System..... | 29 |
| 3.2 Preparing for Installation..... | 7 | 9.0 Commissioning and Startup..... | 32-34 |
| 4.0 Clearances and Dimensions | 8-10 | 9.1 Check the installation prior to startup: | 32 |
| 4.1 Clearances | 8 | 9.2 Heater Startup: | 32 |
| 4.2 Dimensions | 9 | 9.3 Check installation after startup: | 33 |
| 5.0 Hanging the Heater..... | 11-12 | 10.0 Maintenance and Service..... | 34-41 |
| 5.1 Weights | 11 | 10.1 Maintenance Schedule..... | 34 |
| 5.2 Lifting and Suspending | 11 | 10.2 Maintenance Procedures..... | 35 |
| 6.0 Mechanical | 12-20 | 10.3 Troubleshooting | 40 |
| 6.1 Gas Piping and Pressures..... | 12 | APPENDIX | 42 |
| 6.2 Combustion Air - Models UDBP..... | 16 | INDEX..... | 43 |
| 6.3 Unit Discharge..... | 17 | INSTALLATION RECORD | 44 |

1.0 General

1.1 Hazard Labels and Notices

There are warning labels on the unit and throughout this manual. For your safety, read the definitions below and comply with all boxes labeled CAUTION, WARNING, and DANGER during installation, operation, maintenance, and service of this heater.

Definitions of Hazard Intensity Levels in this Manual

HAZARD INTENSITY LEVELS

1. DANGER: Failure to comply will result in severe personal injury or death and/or property damage.
2. WARNING: Failure to comply could result in severe personal injury or death and/or property damage.
3. CAUTION: Failure to comply could result in minor personal injury and/or property damage.

WARNING

Gas-fired appliances are not designed for use in hazardous atmospheres containing flammable vapors or combustible dust, in atmospheres containing chlorinated or halogenated hydrocarbons, or in applications with airborne silicone substances. See Hazard Levels, above.

WARNING

Should overheating occur, or the gas supply control system fail to shut off the flow of gas, shut off the manual gas valve to the appliance before shutting off the electrical supply.

WARNING

Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and replace any gas control that has been under water.

1.2 General

Installation Information

1.2.1 Certification



Model UDBP 30 - 400 and Model UDBS 30 - 400 are design certified by the Canadian Standards Association for use in industrial and commercial installations.

All models and sizes are available for use with either natural or propane gas. The type of gas, the gas input rate, and the electrical supply requirement are shown on the heater rating plate. Check the rating plate to verify that the heater is appropriate for the installation site.

CAUTION

Models UDBP & UDBS unit heaters should not be installed in an environment where the ambient temperature is below 50°F. The low space temperature may result in condensate forming in the heat exchanger.

BOTH this manual and the correct venting manual are REQUIRED for installation of this heater.

| Model | Venting Instruction Manual by Form No. | Look for Matching Label on Venting Manual and Heater |
|-------|---|---|
| UDBP | Form I-UD-V-PV, Standard Power Vent Installation (Each heater has its own dedicated vent.) | Label with a RED SQUARE  |
| UDBS | Form I-UD-V-SC, Separated Combustion (Model UDBS requires field installation of either Option CC2, CC6, or CC14 Vent/Combustion Air Kit) | Label with a GREEN CIRCLE  |

1.2.2 Venting Manual

Installation requires both this manual **AND** the venting manual.

Venting Manual by Model

Both this installation manual and the appropriate venting manual are shipped with the heater. Verify that the literature is correct for the heater being installed. If either manual is missing or incorrect, contact your distributor before beginning installation.

The instructions in this manual apply **only** to the Model UDBP and Model UDBS.

Installation should be done by a qualified agency in accordance with these instructions. The qualified service agency installing this heater is responsible for the installation.

1.3 Warranty

Refer to the limited warranty information on the Warranty Card in the "Literature Bag".

Warranty is void if ...

- Wiring is not in accordance with the diagram furnished with the heater.
- The unit is installed without proper clearance to combustible materials.

1.4 Installation Codes

These units must be installed in accordance with local building codes. In the absence of local codes, in the United States, the unit must be installed in accordance with the National Fuel Gas Code, ANSI Z223.1. A Canadian installation must be in accordance with the CSA B149 Installation Codes. These codes are available from CSA Information Services, 1-800-463-6727. Local authorities having jurisdiction should be consulted before installation is made to verify local codes and installation procedure requirements.

Special Installations (Aircraft Hangars and Garages)

Installations in aircraft hangars should be in accordance with ANSI/NFPA No. 409 (latest edition), Standard for Aircraft Hangars; in public garages in accordance with ANSI/NFPA No. 88A (latest edition), Standard for Parking Structures; and for repair garages in accordance with ANSI/NFPA No. 88B (latest edition), Standard for Repair Garages. In Canada, installations in aircraft hangars should be in accordance with the requirements of the enforcing authorities, and in public garages in accordance with CSA B149 codes.

If the heater is being installed in the state of California, the installer **MUST** attach a warning label on the outside of the access door. The California Warning label is shipped in the literature bag along with this manual, the warranty form, and any other paperwork that applies.

California Warning Label

If installation is in California, select a location on the heater access panel. Be sure the surface is clean and dry and adhere the label.

Massachusetts Requirement

If the heater is being installed in the Commonwealth of Massachusetts, these units must be installed by a licensed plumber or licensed gas fitter.

2.0 Unit Heater Location

Use the clearances in Paragraph 4.1; the combustion air requirements in Paragraph 6.2; the throw tables, sound data, mounting height requirements, and location recommendations in Paragraphs 2; the weights in Paragraph 5.1; and the venting requirements in the Venting Manual to determine where to suspend the heater.


CAUTION

Model UDBP & UDBS unit heaters should not be used in an application where the heated space temperature is below 50° F (10°C). Operating under low ambient conditions may cause condensate to form in the heat exchanger.

2.1 Heater Throw

FIGURE 1 - Throw for Fan Models UDBP and UDBS

NOTE: Throws listed are with standard adjustable horizontal louvers at the angles listed (angle is relative to the top of the heater). Throw pattern changes with the addition of optional vertical louvers and/or downturn nozzles.



Dimensions X, Y, and Z (feet) Model UDBP and Model UDBS with Standard Horizontal Louvers at Mounting Heights of 5-18 ft

| Motor Speed | H | 30 | | | | 45 | | | | 60 | | | | 75 | | | | 100 | | | | 125 | | | |
|--------------|-------|----|----|----|---------------|----|----|----|---------------|----|----|-----|---------------|----|----|----|---------------|-----|----|-----|---------------|-----|----|-----|---------------|
| | | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* |
| Low Speed | 5 ft | 7 | 15 | 38 | -27° | 7 | 17 | 44 | -20° | 11 | 26 | 78 | -15° | 11 | 24 | 74 | -13° | 10 | 23 | 74 | -16° | 10 | 22 | 69 | -14° |
| | 8 ft | 7 | 13 | 32 | -44° | 9 | 17 | 40 | -34° | 14 | 26 | 76 | -23° | 13 | 26 | 72 | -23° | 13 | 25 | 72 | -25° | 12 | 24 | 65 | -24° |
| | 10 ft | 7 | 11 | 25 | -56° | 9 | 16 | 37 | -42° | 15 | 27 | 72 | -29° | 15 | 25 | 69 | -28° | 14 | 25 | 69 | -31° | 13 | 24 | 62 | -31° |
| | 12 ft | - | - | - | - | 9 | 14 | 31 | -52° | 16 | 26 | 70 | -34° | 15 | 25 | 65 | -34° | 14 | 24 | 66 | -37° | 14 | 23 | 58 | -37° |
| | 14 ft | - | - | - | - | - | - | - | - | 16 | 25 | 65 | -40° | 15 | 24 | 62 | -40° | 14 | 23 | 62 | -43° | 14 | 21 | 54 | -43° |
| | 16 ft | - | - | - | - | - | - | - | - | 15 | 24 | 60 | -46° | 15 | 23 | 56 | -46° | 14 | 21 | 57 | -49° | 12 | 19 | 47 | -51° |
| Medium Speed | 5 ft | 7 | 16 | 43 | -24° | 9 | 21 | 60 | -15° | 12 | 28 | 91 | -13° | 11 | 27 | 84 | -11° | 11 | 27 | 86 | -13° | 12 | 29 | 96 | -10° |
| | 8 ft | 9 | 16 | 38 | -38° | 11 | 23 | 57 | -26° | 16 | 30 | 89 | -21° | 15 | 29 | 82 | -19° | 15 | 28 | 83 | -21° | 16 | 31 | 94 | -18° |
| | 10 ft | 8 | 14 | 33 | -48° | 13 | 22 | 54 | -32° | 17 | 30 | 86 | -26° | 16 | 30 | 79 | -25° | 17 | 29 | 81 | -26° | 18 | 32 | 92 | -23° |
| | 12 ft | 8 | 12 | 28 | -56° | 13 | 21 | 51 | -39° | 18 | 31 | 83 | -31° | 17 | 30 | 77 | -30° | 17 | 29 | 78 | -32° | 19 | 32 | 89 | -27° |
| | 14 ft | - | - | - | - | 12 | 20 | 46 | -46° | 18 | 30 | 79 | -36° | 18 | 29 | 74 | -34° | 18 | 29 | 74 | -37° | 20 | 32 | 87 | -32° |
| | 16 ft | - | - | - | - | 11 | 17 | 40 | -53° | 19 | 29 | 75 | -41° | 18 | 28 | 70 | -39° | 18 | 27 | 70 | -42° | 20 | 31 | 83 | -36° |
| High Speed | 5 ft | 8 | 19 | 51 | -20° | 11 | 28 | 81 | -11° | 13 | 30 | 105 | -11° | 12 | 30 | 97 | -09° | 13 | 32 | 110 | -10° | 13 | 33 | 113 | -7° |
| | 8 ft | 10 | 19 | 48 | -31° | 15 | 29 | 79 | -19° | 17 | 33 | 103 | -19° | 17 | 33 | 95 | -16° | 18 | 34 | 108 | -17° | 19 | 36 | 111 | -13° |
| | 10 ft | 11 | 19 | 44 | -39° | 16 | 30 | 78 | -24° | 19 | 34 | 100 | -23° | 19 | 33 | 94 | -20° | 20 | 36 | 106 | -21° | 21 | 37 | 109 | -17° |
| | 12 ft | 11 | 17 | 40 | -46° | 17 | 30 | 75 | -29° | 21 | 35 | 98 | -27° | 20 | 34 | 92 | -25° | 22 | 36 | 104 | -25° | 23 | 39 | 107 | -21° |
| | 14 ft | 9 | 15 | 33 | -56° | 18 | 30 | 72 | -34° | 22 | 34 | 95 | -31° | 21 | 34 | 89 | -29° | 23 | 36 | 102 | -29° | 24 | 39 | 105 | -25° |
| | 16 ft | - | - | - | - | 19 | 29 | 69 | -39° | 23 | 33 | 91 | -35° | 22 | 33 | 86 | -33° | 24 | 36 | 99 | -33° | 25 | 40 | 103 | -29° |
| | 18 ft | - | - | - | - | 18 | 28 | 64 | -44° | 21 | 33 | 86 | -40° | 22 | 33 | 83 | -37° | 23 | 36 | 95 | -37° | 26 | 39 | 101 | -32° |

| H | 150 | | | | 175 | | | | 200 | | | | 225 | | | | 250 | | | | 300 | | | | 350 | | | | 400 | | | |
|---|-----|----|----|---------------|-----|----|----|---------------|-----|----|-----|---------------|-----|----|-----|---------------|-----|----|-----|---------------|-----|----|-----|---------------|-----|----|-----|---------------|-----|----|-----|---------------|
| | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* |
| 75°F Temperature Rise for Sizes 150-350; 80°F Temperature Rise for Size 400 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 ft | 9 | 16 | 44 | -39° | 12 | 22 | 69 | -30° | 13 | 24 | 76 | -27° | 13 | 24 | 82 | -29° | 14 | 27 | 95 | -26° | 12 | 21 | 70 | -32° | 13 | 25 | 82 | -27° | 15 | 28 | 95 | -24° |
| 10 ft | 9 | 14 | 38 | -48° | 12 | 22 | 65 | -37° | 14 | 24 | 72 | -33° | 12 | 21 | 66 | -38° | 16 | 27 | 91 | -31° | 12 | 21 | 65 | -39° | 14 | 25 | 77 | -33° | 16 | 28 | 92 | -29° |
| 12 ft | 7 | 11 | 30 | -58° | 13 | 21 | 59 | -43° | 14 | 23 | 68 | -39° | 12 | 20 | 60 | -45° | 16 | 27 | 86 | -37° | 12 | 19 | 58 | -47° | 14 | 24 | 72 | -40° | 17 | 28 | 88 | -34° |
| 14 ft | - | - | - | - | 11 | 19 | 52 | -51° | 14 | 22 | 62 | -46° | 11 | 18 | 53 | -52° | 16 | 25 | 80 | -43° | 10 | 17 | 50 | -55° | 14 | 22 | 66 | -46° | 17 | 27 | 82 | -39° |
| 16 ft | - | - | - | - | - | - | - | - | 12 | 20 | 53 | -53° | - | - | - | - | 16 | 23 | 73 | -49° | - | - | - | - | 13 | 20 | 57 | -53° | 17 | 26 | 76 | -45° |
| 18 ft | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 14 | 21 | 64 | -56° | - | - | - | - | - | - | - | - | - | - | - | - |
| 60°F Temperature Rise for Sizes 150-350; 70°F Temperature Rise for Size 400 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 ft | 13 | 24 | 74 | -28° | 15 | 29 | 92 | -22° | 16 | 31 | 100 | -21° | 16 | 29 | 100 | -24° | 19 | 34 | 127 | -20° | 16 | 28 | 100 | -24° | 18 | 33 | 119 | -20° | 17 | 31 | 111 | -21° |
| 10 ft | 13 | 22 | 62 | -35° | 16 | 29 | 89 | -28° | 18 | 31 | 97 | -25° | 16 | 30 | 96 | -29° | 20 | 35 | 123 | -24° | 17 | 29 | 96 | -29° | 19 | 34 | 116 | -25° | 18 | 32 | 107 | -26° |
| 12 ft | 13 | 21 | 57 | -42° | 17 | 29 | 85 | -33° | 19 | 31 | 93 | -30° | 17 | 30 | 92 | -34° | 21 | 36 | 120 | -28° | 18 | 29 | 92 | -34° | 21 | 34 | 113 | -29° | 19 | 32 | 103 | -31° |
| 14 ft | 12 | 19 | 51 | -49° | 17 | 28 | 80 | -38° | 20 | 30 | 89 | -34° | 18 | 28 | 87 | -38° | 22 | 35 | 116 | -32° | 18 | 28 | 87 | -39° | 22 | 34 | 109 | -33° | 20 | 31 | 99 | -35° |
| 16 ft | 11 | 16 | 43 | -57° | 17 | 27 | 75 | -43° | 20 | 29 | 84 | -39° | 18 | 27 | 80 | -44° | 23 | 35 | 111 | -37° | 18 | 27 | 81 | -44° | 22 | 33 | 104 | -37° | 20 | 31 | 93 | -40° |
| 18 ft | - | - | - | - | 17 | 25 | 69 | -48° | 19 | 29 | 79 | -44° | 17 | 26 | 74 | -49° | 23 | 34 | 106 | -41° | 17 | 25 | 73 | -50° | 22 | 32 | 98 | -41° | 20 | 29 | 88 | -44° |

| H | 150 | | | | 175 | | | | 200 | | | | 225 | | | | 250 | | | | 300 | | | | 350 | | | | 400 | | | |
|---|-----|----|-----|---------------|-----|----|-----|---------------|-----|----|-----|---------------|-----|----|-----|---------------|-----|----|-----|---------------|-----|----|-----|---------------|-----|----|-----|---------------|-----|----|-----|---------------|
| | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* |
| 45°F Temperature Rise for Sizes 150-350; 50°F Temperature Rise for Size 400 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 ft | 18 | 32 | 107 | -19° | 22 | 41 | 146 | -15° | 23 | 43 | 157 | -13° | 23 | 43 | 168 | -16° | 26 | 48 | 198 | -14° | 21 | 39 | 146 | -17° | 24 | 45 | 169 | -14° | 24 | 44 | 169 | -14° |
| 10 ft | 19 | 34 | 104 | -24° | 24 | 43 | 144 | -19° | 25 | 46 | 155 | -17° | 26 | 45 | 166 | -19° | 29 | 50 | 196 | -17° | 23 | 41 | 143 | -21° | 26 | 47 | 167 | -18° | 26 | 46 | 167 | -17° |
| 12 ft | 21 | 34 | 102 | -28° | 26 | 43 | 141 | -22° | 27 | 47 | 152 | -20° | 28 | 45 | 163 | -22° | 31 | 52 | 194 | -20° | 25 | 42 | 140 | -25° | 28 | 48 | 165 | -21° | 28 | 48 | 165 | -20° |
| 14 ft | 22 | 34 | 98 | -32° | 28 | 44 | 137 | -25° | 29 | 48 | 150 | -23° | 30 | 46 | 160 | -25° | 32 | 54 | 191 | -22° | 26 | 42 | 137 | -28° | 30 | 49 | 162 | -24° | 31 | 48 | 162 | -23° |
| 16 ft | 22 | 33 | 94 | -36° | 29 | 44 | 134 | -28° | 31 | 48 | 147 | -26° | 31 | 47 | 157 | -29° | 34 | 53 | 189 | -25° | 27 | 42 | 133 | -31° | 32 | 48 | 159 | -26° | 32 | 49 | 159 | -26° |
| 18 ft | 21 | 33 | 89 | -41° | 29 | 44 | 131 | -32° | 31 | 49 | 144 | -29° | 31 | 47 | 153 | -32° | 34 | 54 | 185 | -28° | 28 | 41 | 129 | -34° | 33 | 49 | 156 | -29° | 32 | 49 | 156 | -29° |

Dimensions X, Y, Z (meters) Model UDBP and Model UDBS with Standard Horizontal Louvers at Mounting Heights of 1.5 - 5.5M

| Motor Speed | H | 30 | | | | 45 | | | | 60 | | | | 75 | | | | 100 | | | | 125 | | | |
|--------------|------|-----|-----|------|---------------|-----|-----|------|---------------|-----|------|------|---------------|-----|------|------|---------------|-----|------|------|---------------|-----|------|------|---------------|
| | | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* |
| Low Speed | 1.5M | 2.1 | 4.6 | 11.6 | -27° | 2.1 | 5.2 | 13.4 | -20° | 3.4 | 7.9 | 23.8 | -15° | 3.4 | 7.3 | 22.6 | -13° | 3.0 | 7.0 | 22.6 | -16° | 3.0 | 6.7 | 21.0 | -14° |
| | 2.4M | 2.1 | 4.0 | 9.8 | -44° | 2.7 | 5.2 | 12.2 | -34° | 4.3 | 7.9 | 23.2 | -23° | 4.0 | 7.9 | 21.9 | -23° | 4.0 | 7.6 | 21.9 | -25° | 3.7 | 7.3 | 19.8 | -24° |
| | 3.0M | 2.1 | 3.4 | 7.6 | -56° | 2.7 | 4.9 | 11.3 | -42° | 4.6 | 8.2 | 21.9 | -29° | 4.6 | 7.6 | 21.0 | -28° | 4.3 | 7.6 | 21.0 | -31° | 4.0 | 7.3 | 18.9 | -31° |
| | 3.7M | - | - | - | - | 2.7 | 4.3 | 9.4 | -52° | 4.9 | 7.9 | 21.3 | -34° | 4.6 | 7.6 | 19.8 | -34° | 4.3 | 7.3 | 20.1 | -37° | 4.3 | 7.0 | 17.7 | -37° |
| | 4.3M | - | - | - | - | - | - | - | - | 4.9 | 7.6 | 19.8 | -40° | 4.6 | 7.3 | 18.9 | -40° | 4.3 | 7.0 | 18.9 | -43° | 4.3 | 6.4 | 16.5 | -43° |
| | 4.9M | - | - | - | - | - | - | - | - | 4.6 | 7.3 | 18.3 | -46° | 4.6 | 7.0 | 17.1 | -46° | 4.3 | 6.4 | 17.4 | -49° | 3.7 | 5.8 | 14.3 | -51° |
| Medium Speed | 1.5M | 2.1 | 4.9 | 13.1 | -24° | 2.7 | 6.4 | 18.3 | -15° | 3.7 | 8.5 | 27.7 | -13° | 3.4 | 8.2 | 25.6 | -11° | 3.4 | 8.2 | 26.2 | -13° | 3.7 | 8.8 | 29.3 | -10° |
| | 2.4M | 2.7 | 4.9 | 11.6 | -38° | 3.4 | 7.0 | 17.4 | -26° | 4.9 | 9.1 | 27.1 | -21° | 4.6 | 8.8 | 25.0 | -19° | 4.6 | 8.5 | 25.3 | -21° | 4.9 | 9.4 | 28.7 | -18° |
| | 3.0M | 2.4 | 4.3 | 10.1 | -48° | 4.0 | 6.7 | 16.5 | -32° | 5.2 | 9.1 | 26.2 | -26° | 4.9 | 9.1 | 24.1 | -25° | 5.2 | 8.8 | 24.7 | -26° | 5.5 | 9.8 | 28.0 | -23° |
| | 3.7M | 2.4 | 3.7 | 8.5 | -56° | 4.0 | 6.4 | 15.5 | -39° | 5.5 | 9.4 | 25.3 | -31° | 5.2 | 9.1 | 23.5 | -30° | 5.2 | 8.8 | 23.8 | -32° | 5.8 | 9.8 | 27.1 | -27° |
| | 4.3M | - | - | - | - | 3.7 | 6.1 | 14.0 | -46° | 5.5 | 9.1 | 24.1 | -36° | 5.5 | 8.8 | 22.6 | -34° | 5.5 | 8.8 | 22.6 | -37° | 6.1 | 9.8 | 26.5 | -32° |
| | 4.9M | - | - | - | - | 3.4 | 5.2 | 12.2 | -53° | 5.8 | 8.8 | 22.9 | -41° | 5.5 | 8.5 | 21.3 | -39° | 5.5 | 8.2 | 21.3 | -42° | 6.1 | 9.4 | 25.3 | -36° |
| High Speed | 1.5M | 2.4 | 5.8 | 15.5 | -20° | 3.4 | 8.5 | 24.7 | -11° | 4.0 | 9.1 | 32.0 | -11° | 3.7 | 9.1 | 29.6 | -09° | 4.0 | 9.8 | 33.5 | -10° | 4.0 | 10.1 | 34.4 | -7° |
| | 2.4M | 3.0 | 5.8 | 14.6 | -31° | 4.6 | 8.8 | 24.1 | -19° | 5.2 | 10.1 | 31.4 | -19° | 5.2 | 10.1 | 29.0 | -16° | 5.5 | 10.4 | 32.9 | -17° | 5.8 | 11.0 | 33.8 | -13° |
| | 3.0M | 3.4 | 5.8 | 13.4 | -39° | 4.9 | 9.1 | 23.8 | -24° | 5.8 | 10.4 | 30.5 | -23° | 5.8 | 10.1 | 28.7 | -20° | 6.1 | 11.0 | 32.3 | -21° | 6.4 | 11.3 | 33.2 | -17° |
| | 3.7M | 3.4 | 5.2 | 12.2 | -46° | 5.2 | 9.1 | 22.9 | -29° | 6.4 | 10.7 | 29.9 | -27° | 6.1 | 10.4 | 28.0 | -25° | 6.7 | 11.0 | 31.7 | -25° | 7.0 | 11.9 | 32.6 | -21° |
| | 4.3M | 2.7 | 4.6 | 10.1 | -56° | 5.5 | 9.1 | 21.9 | -34° | 6.7 | 10.4 | 29.0 | -31° | 6.4 | 10.4 | 27.1 | -29° | 7.0 | 11.0 | 31.1 | -29° | 7.3 | 11.9 | 32.0 | -25° |
| | 4.9M | - | - | - | - | 5.8 | 8.8 | 21.0 | -39° | 7.0 | 10.1 | 27.7 | -35° | 6.7 | 10.1 | 26.2 | -33° | 7.3 | 11.0 | 30.2 | -33° | 7.6 | 12.2 | 31.4 | -29° |
| | 5.5M | - | - | - | - | 5.5 | 8.5 | 19.5 | -44° | 6.4 | 10.1 | 26.2 | -40° | 6.7 | 10.1 | 25.3 | -37° | 7.0 | 11.0 | 29.0 | -37° | 7.9 | 11.9 | 30.8 | -32° |

| H | 150 | | | | 175 | | | | 200 | | | | 225 | | | | 250 | | | | 300 | | | | 350 | | | | 400 | | | |
|---|-----|------|------|---------------|-----|------|------|---------------|-----|------|------|---------------|-----|------|------|---------------|------|------|------|---------------|-----|------|------|---------------|------|------|------|---------------|-----|------|------|---------------|
| | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* | X | Y | Z | Louver Angle* |
| 75°F Temperature Rise for Sizes 150-350; 80°F Temperature Rise for Size 400 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2.4M | 2.7 | 4.9 | 13.4 | -39° | 3.7 | 6.7 | 21.0 | -30° | 4.0 | 7.3 | 23.2 | -27° | 4.0 | 7.3 | 25.0 | -29° | 4.3 | 8.2 | 29.0 | -26° | 3.7 | 6.4 | 21.3 | -32° | 4.0 | 7.6 | 25.0 | -27° | 4.6 | 8.5 | 29.0 | -24° |
| 3.0M | 2.7 | 4.3 | 11.6 | -48° | 3.7 | 6.7 | 19.8 | -37° | 4.3 | 7.3 | 21.9 | -33° | 3.7 | 6.4 | 20.1 | -38° | 4.9 | 8.2 | 27.7 | -31° | 3.7 | 6.4 | 19.8 | -39° | 4.3 | 7.6 | 23.5 | -33° | 4.9 | 8.5 | 28.0 | -29° |
| 3.7M | 2.1 | 3.4 | 9.1 | -58° | 4.0 | 6.4 | 18.0 | -43° | 4.3 | 7.0 | 20.7 | -39° | 3.7 | 6.1 | 18.3 | -45° | 4.9 | 8.2 | 26.2 | -37° | 3.7 | 5.8 | 17.7 | -47° | 4.3 | 7.3 | 21.9 | -40° | 5.2 | 8.5 | 26.8 | -34° |
| 4.3M | - | - | - | - | 3.4 | 5.8 | 15.8 | -51° | 4.3 | 6.7 | 18.9 | -46° | 3.4 | 5.5 | 16.2 | -52° | 4.9 | 7.6 | 24.4 | -43° | 3.0 | 5.2 | 15.2 | -55° | 4.3 | 6.7 | 20.1 | -46° | 5.2 | 8.2 | 25.0 | -39° |
| 4.9M | - | - | - | - | - | - | - | - | 3.7 | 6.1 | 16.2 | -53° | - | - | - | - | 4.9 | 7.0 | 22.3 | -49° | - | - | - | - | 4.0 | 6.1 | 17.4 | -53° | 5.2 | 7.9 | 23.2 | -45° |
| 5.5M | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | - | 4.3 | 6.4 | 19.5 | -56° | - | - | - | - | - | - | - | - | - | - | - | -50° |
| 60°F Temperature Rise for Sizes 150-350; 70°F Temperature Rise for Size 400 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2.4M | 4.0 | 7.3 | 22.6 | -28° | 4.6 | 8.8 | 28.0 | -22° | 4.9 | 9.4 | 30.5 | -21° | 4.9 | 8.8 | 30.5 | -24° | 5.8 | 10.4 | 38.7 | -20° | 4.9 | 8.5 | 30.5 | -24° | 5.5 | 10.1 | 36.3 | -20° | 5.2 | 9.4 | 33.8 | -21° |
| 3.0M | 4.0 | 6.7 | 18.9 | -35° | 4.9 | 8.8 | 27.1 | -28° | 5.5 | 9.4 | 29.6 | -25° | 4.9 | 9.1 | 29.3 | -29° | 6.1 | 10.7 | 37.5 | -24° | 5.2 | 8.8 | 29.3 | -29° | 5.8 | 10.4 | 35.4 | -25° | 5.5 | 9.8 | 32.6 | -26° |
| 3.7M | 4.0 | 6.4 | 17.4 | -42° | 5.2 | 8.8 | 25.9 | -33° | 5.8 | 9.4 | 28.3 | -30° | 5.2 | 9.1 | 28.0 | -34° | 6.4 | 11.0 | 36.6 | -28° | 5.5 | 8.8 | 28.0 | -34° | 6.4 | 10.4 | 34.4 | -29° | 5.8 | 9.8 | 31.4 | -31° |
| 4.3M | 3.7 | 5.8 | 15.5 | -49° | 5.2 | 8.5 | 24.4 | -38° | 6.1 | 9.1 | 27.1 | -34° | 5.5 | 8.5 | 26.5 | -38° | 6.7 | 10.7 | 35.4 | -32° | 5.5 | 8.5 | 26.5 | -39° | 6.7 | 10.4 | 33.2 | -33° | 6.1 | 9.4 | 30.2 | -35° |
| 4.9M | 3.4 | 4.9 | 13.1 | -57° | 5.2 | 8.2 | 22.9 | -43° | 6.1 | 8.8 | 25.6 | -39° | 5.5 | 8.2 | 24.4 | -44° | 7.0 | 10.7 | 33.8 | -37° | 5.5 | 8.2 | 24.7 | -44° | 6.7 | 10.1 | 31.7 | -37° | 6.1 | 9.4 | 28.3 | -40° |
| 5.5M | - | - | - | - | 5.2 | 7.6 | 21.0 | -48° | 5.8 | 8.8 | 24.1 | -44° | 5.2 | 7.9 | 22.6 | -49° | 7.0 | 10.4 | 32.3 | -41° | 5.2 | 7.6 | 22.3 | -50° | 6.7 | 9.8 | 29.9 | -41° | 6.1 | 8.8 | 26.8 | -44° |
| 45°F Temperature Rise for Sizes 150-350; 50°F Temperature Rise for Size 400 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2.4M | 5.5 | 9.8 | 32.6 | -19° | 6.7 | 12.5 | 44.5 | -15° | 7.0 | 13.1 | 47.9 | -13° | 7.0 | 13.1 | 51.2 | -16° | 7.9 | 14.6 | 60.4 | -14° | 6.4 | 11.9 | 44.5 | -17° | 7.3 | 13.7 | 51.5 | -14° | 7.3 | 13.4 | 51.5 | -14° |
| 3.0M | 5.8 | 10.4 | 31.7 | -24° | 7.3 | 13.1 | 43.9 | -19° | 7.6 | 14.0 | 47.2 | -17° | 7.9 | 13.7 | 50.6 | -19° | 8.8 | 15.2 | 59.7 | -17° | 7.0 | 12.5 | 43.6 | -21° | 7.9 | 14.3 | 50.9 | -18° | 7.9 | 14.0 | 50.9 | -17° |
| 3.7M | 6.4 | 10.4 | 31.1 | -28° | 7.9 | 13.1 | 43.0 | -22° | 8.2 | 14.3 | 46.3 | -20° | 8.5 | 13.7 | 49.7 | -22° | 9.4 | 15.8 | 59.1 | -20° | 7.6 | 12.8 | 42.7 | -25° | 8.5 | 14.6 | 50.3 | -21° | 8.5 | 14.6 | 50.3 | -20° |
| 4.3M | 6.7 | 10.4 | 29.9 | -32° | 8.5 | 13.4 | 41.8 | -25° | 8.8 | 14.6 | 45.7 | -23° | 9.1 | 14.0 | 48.8 | -25° | 9.8 | 16.5 | 58.2 | -22° | 7.9 | 12.8 | 41.8 | -28° | 9.1 | 14.9 | 49.4 | -24° | 9.4 | 14.6 | 49.4 | -23° |
| 4.9M | 6.7 | 10.1 | 28.7 | -36° | 8.8 | 13.4 | 40.8 | -28° | 9.4 | 14.6 | 44.8 | -26° | 9.4 | 14.3 | 47.9 | -29° | 10.4 | 16.2 | 57.6 | -25° | 8.2 | 12.8 | 40.5 | -31° | 9.8 | 14.6 | 48.5 | -26° | 9.8 | 14.9 | 48.5 | -26° |
| 5.5M | 6.4 | 10.1 | 27.1 | -41° | 8.8 | 13.4 | 39.9 | -32° | 9.4 | 14.9 | 43.9 | -29° | 9.4 | 14.3 | 46.6 | -32° | 10.4 | 16.5 | 56.4 | -28° | 8.5 | 12.5 | 39.3 | -34° | 10.1 | 14.9 | 47.5 | -29° | 9.8 | 14.9 | 47.5 | -29° |

2.0 Unit Heater Location (cont'd)

NOTE: Venting requirements may affect location. Consult the Venting Manual for this heater before making final determination.

Hazards of Chlorine - applies to location of Model UDBS heater with regard to combustion air inlet

3.0 Uncrating and Preparation

2.3 Location Recommendations

Locate the heater so that it is a minimum of five feet (1.5M) above the floor and in compliance with the clearances in Paragraph 4.1.

WARNING

If touched, the vent pipe and internal heater surfaces that are accessible from outside the heater will cause burns. Suspend the heater a minimum of 5 feet (1.5M) above the floor.

For best results, the heater should be placed with certain rules in mind. In general, a unit should be located from 8 to 12 feet (2.4-3.7M) above the floor. Units should always be arranged to blow toward or along exposed wall surfaces, if possible. Where two or more units are installed in the same room, a general scheme of air circulation should be maintained for best results.

Suspended heaters are most effective when located as close to the working zone as possible, and this fact should be kept in mind when determining the mounting heights to be used. However, care should be exercised to avoid directing the discharged air directly on the room occupants.

Partitions, columns, counters, or other obstructions should be taken into consideration when locating the unit heater so that a minimum quantity of airflow will be deflected by such obstacles.

When units are located in the center of the space to be heated, the air should be discharged toward the exposed walls. In large areas, units should be located to discharge air along exposed walls with extra units provided to discharge air in toward the center of the area.

At those points where infiltration of cold air is excessive, such as at entrance doors and shipping doors, it is desirable to locate the unit so that it will discharge directly toward the source of cold air from a distance of 15 to 20 feet (4.6-6.1M).

CAUTION: Do not locate the heater where it may be exposed to water spray, rain, or dripping water.

For a location where dirt, dust, or other airborne contaminants are present in the indoor environment, it is recommended to install a separated-combustion unit, Model UDBS, that uses outside air for combustion. Using a separated-combustion unit will reduce the build-up of contaminants on the burner. Any buildup on the burner will adversely affect the combustion process.

The presence of chlorine vapors in the combustion air of gas-fired heating equipment presents a potential corrosion hazard. Chlorine found usually in the form of freon or degreaser vapors, when exposed to flame will precipitate from the compound, and go into solution with any condensation that is present in the heat exchanger or associated parts. The result is hydrochloric acid which readily attacks all metals including 300 grade stainless steel. Care should be taken to separate these vapors from the combustion process. This may be done by wise location of the unit vent and combustion air terminals with regard to exhausters or prevailing wind directions. Chlorine is heavier than air. Keep these facts in mind when determining installation location of the heater in relation to building exhaust systems.

3.1 Uncrating and Inspecting

This unit was test operated and inspected at the factory prior to crating and was in operating condition. If the heater has incurred any damage in shipment, document the damage with the transporting agency and contact an authorized Reznor® Distributor. If you are an authorized Distributor, follow the FOB freight policy procedures as published by Reznor for Reznor® products.

Check the rating plate for the gas specifications and electrical characteristics of the heater to be sure that they are compatible with the gas and electric supplies at the installation site.

3.2 Preparing for Installation

Read this booklet and become familiar with the installation requirements of your particular heater. If you do not have knowledge of local requirements, check with the local gas company or any other local agencies who might have requirements concerning this installation. Before beginning, make preparations for necessary supplies, tools, and manpower.

IMPORTANT: Shipping brackets are attached with cabinet screws. When removing shipping brackets, re-insert ALL screws into the cabinet.

To protect the unit during shipping, the heater has supports that must be removed before installation. Follow these instructions to remove:

- ☐ Blower Support Legs - Remove the two blower support legs and screws.
- ☐ Motor Shipping Block (belt drive units) - Remove the wooden block located under the motor bracket. Find the two rubber bushings shipped in the "Literature Bag". Place the bushings on the ends of the motor bracket bolts.
- ☐ Motor Shipping Plate - Models equipped with belt drive motors of 3/4 HP or less have a metal shipping plate attached between the motor and the blower housing. Remove and discard the shipping plate. **NOTE:** On units factory equipped with an optional belt guard, the belt guard must be removed in order to reach the shipping the plate.

Field-Installed Parts

If installing a Model UDBP or UDBS 150-400 ordered for use with 460 or 575 supply voltage, a field-installed 500VA transformer is shipped separately. Be sure the transformer is there and follow the instructions in Paragraph 7.2 to attach it to the factory-installed bracket.

| Model UDB Size | 150-200 | 225-250 | 300-400 |
|--|------------|--------------|---------------------------|
| Shipped-Separate Package P/N for 460V/3ph Supply | 198503 | 198504 | 198505 |
| 460V - 120V Transformer | P/N 11100 | | |
| Shipped-Separate Package P/N for 575V/3ph Supply | 198506 | 198507 | 198508 |
| 575V - 120V Transformer | P/N 202056 | | |
| Components of both the 460V and the 575V Shipped-Separate Pacakge (above): | | | |
| Description of Parts | Qty | P/N's | |
| 3/8" x 3/4" long Hex Head Cap Screw | 1 | 32253 | |
| 3/8" Lockwasher | 1 | 5197 | |
| 3/8" Flat Washer | 2 | 6593 | |
| BX Cable 3/8" | 1 | 63292 (49") | 10460 (56") 201465 (70") |
| Straight Connector | 1 | 16202 | |
| 90° Connector | 1 | 1417 | |
| Anti-short Bushing | 2 | 16358 | |
| Black Wire 14 GA, 105°C | 1 | 123150 (65") | 48862 (72") 201466 (86") |
| White Wire 14 GA, 105°C | 1 | 123152 (65") | 48861 (72") 201467 (86") |
| Green Wire14 GA, 105°C | 1 | 201468 (65") | 201462 (72") 201469 (86") |
| Cable Clamp, 1/2" | 1 | 16227 | |
| #10 X 1/2" long Sheetmetal Screw | 3 | 11813 | |
| Twist-on Wire Connector | 10 | 16354 | |

If the installation includes optional vertical louvers, downturn nozzle, polytube adapter, duct flange, belt guard, blower guard, hanger kit, high altitude kit, multiple heater control, sensor for DDC control, and/or stepdown transformer, **install these options before the heater is suspended.** Complete instructions are in this form or in the option package; option packages are shipped separately.

Other shipped separate items could include a vent cap (Option CC1 for UDBP); a vent/combustion air kit (Option CC2 or CC6 for UDBS); a manual gas valve; a thermostat bracket kit; a thermostat; and/or a thermostat guard.

Be sure all options ordered are at the installation site.

High Altitude Kit, Option DJ20 or DJ21

If the heater is being installed at an elevation above 2000 ft (610M), the input rate will have to be derated. This is done by adjusting the valve outlet pressure.

In addition, if the heater is being installed at an altitude above 6000 ft (1830M), the pressure switch will have to be changed. If ordered with the unit as Option DJ20 or DJ21, the pressure switch is shipped separately for field installation.

Adjusting the valve outlet pressure is done after the heater is in operation; follow the instructions in Paragraph 6.1. Capacities and inputs for derated units are also listed in Paragraph 6.1.

Gas valve adjustment for high altitude can only be done after heater is operating; see Paragraph 6.1.

3.0 Uncrating and Preparation (cont'd)

3.2 Preparing for Installation (cont'd)

If the pressure switch needs to be changed, do that before the heater is operated; follow the instructions in **FIGURE 2**.

FIGURE 2 - Installing High Altitude Pressure Switch required above 6000 ft (1830M) elevation



Pressure Switch

Model UDBP

| Size | 30 | 45 | 60 | 75 | 100 | 125 | 150 | 175 | 200 | 225 | 250 | 300 | 350 | 400 |
|--|--------|----|--------|----|--------|-----|-----|-----|--------|-----|-----|-----|-----|-----|
| High Altitude Switch P/N | 197031 | | 197032 | | 197031 | | | | 201160 | | | | | |
| Negative Pressure OFF Setpoint ("w.c.) | 0.35 | | 0.45 | | 0.35 | | | | 1.05 | | | | | |
| Label color | Purple | | Pink | | Purple | | | | Brown | | | | | |

Model UDBS

| Size | 30 | 45 | 60 | 75 | 100 | 125 | 150 | 175 | 200 | 225 | 250 | 300 | 350 | 400 |
|--|--------|--------|--------|--------|--------|--------|--------|--------|-----|-----|-----|-----|-----|-----|
| High Altitude Switch P/N | 197031 | 197032 | 196362 | 197032 | 197031 | 197030 | 197031 | 201160 | | | | | | |
| Differential Pressure OFF Setpoint ("w.c.) | 0.35 | 0.45 | 0.55 | 0.45 | 0.35 | 0.40 | 0.35 | 1.05 | | | | | | |
| Label color | Purple | Pink | White | Pink | Purple | Green | Purple | Brown | | | | | | |


Instructions for Changing Pressure Switch

1. In the control compartment, locate the pressure switch.
2. Mark and disconnect the two wires attached to the pressure switch.
3. Disconnect the sensing tubes from the pressure switch.
4. Locate the two screws holding the switch mounting bracket. Remove the screws and the pressure switch. Save the screws.
5. Using the same screws, install the high altitude pressure switch. Attach the sensing tubes and wires.

Downturn Nozzle Kits, Option CD 2, 3, 4, or 5

Follow the instructions with the kit to install. Additional length beyond the front of the unit is shown in **FIGURE 3**.

FIGURE 3 - With Optional Downturn Nozzle, Dimension "A"




| UDBP and UDBS Sizes | Dimension A | | | |
|---------------------|-------------------|-----|-------------------|-----|
| | Options CD2 & CD4 | | Options CD3 & CD5 | |
| | inches | mm | inches | mm |
| 30, 45 | 7-1/8 | 181 | 12-3/8 | 314 |
| 60, 75 | 8-5/8 | 219 | 15 | 381 |
| 100, 125 | 12-5/8 | 321 | 21-7/8 | 556 |
| 150, 175, 200 | 11-1/2 | 292 | 19-7/8 | 505 |
| 225, 250 | 14-1/2 | 368 | 25-1/8 | 638 |
| 300, 350, 400 | 18-1/2 | 470 | 32 | 813 |

4.0 Clearances and Dimensions

4.1 Clearances

Units must be installed so that the clearances in **FIGURE 4** are provided for combustion air space, inspection and service, and for proper spacing from combustible construction. Clearance to combustibles is defined as the minimum distance from the heater to a surface or object that is necessary to ensure that a surface temperature of 90°F above the surrounding ambient temperature is not exceeded.


FIGURE 4 - Clearances



| UDBP and UDBS Sizes | 30-125 | | 150-400 | |
|---------------------|--------|-----|---------|-----|
| | inches | mm | inches | mm |
| Top* | 6 | 152 | 14 | 356 |
| Flue Connector | 6 | 152 | 6 | 152 |
| Access Panel | 18 | 457 | 18 | 457 |
| *Non-Access Side | 24 | 610 | 24 | 610 |
| Bottom | 1 | 25 | 1 | 25 |
| Rear | 18 | 457 | 18 | 457 |

4.2 Dimensions

FIGURE 5 - Model UDBP, Power Vented Fan Model



NOTES: *Sizes 150-400 - Dimension E varies with motor selection and belt adjustment.

**Dimensions H and K are the heater suspension points.

Model UDBP Dimensions (inches ± 1/16)

| Size | A | B | C | D | E | F | G | H | J | K | L | M | N | P | Q | R | S | T |
|---------------|--------|--------|----------|----|---------|---------|---------|--------|--------|--------|-------|---------|---------|----------|--------|-------|--------|----|
| 30, 45 | 26-5/8 | 12-1/8 | 13-13/16 | 10 | 16-3/8 | 36-1/8 | 21-9/16 | 17-3/8 | 11/16 | 22-1/2 | 6-1/2 | 9-3/16 | 5-3/16 | 2-11/16 | 2-7/8 | 3-7/8 | 6-1/2 | 31 |
| 60 | 26-5/8 | 15-1/8 | 13-13/16 | 13 | 17-7/8 | 36-1/8 | 21-9/16 | 17-3/8 | 11/16 | 22-1/2 | 6-1/2 | 11-7/8 | 7-7/8 | 5-1/2 | 2-7/8 | 3-7/8 | 6-1/2 | 31 |
| 75 | 26-5/8 | 15-1/8 | 13-13/16 | 13 | 17-7/8 | 36-1/8 | 21-9/16 | 17-3/8 | 11/16 | 22-1/2 | 5-1/2 | 11-7/8 | 7-7/8 | 5-1/2 | 2-7/8 | 3-7/8 | 6-1/2 | 31 |
| 100 | 26-5/8 | 23-1/8 | 13-13/16 | 21 | 23-1/4 | 43-5/8 | 21-9/16 | 17-3/8 | 11/16 | 22-1/2 | 8-1/2 | 18-1/2 | 14-1/2 | 8-3/4 | 2-7/8 | 3-7/8 | 6-7/16 | 31 |
| 125 | 26-5/8 | 23-1/8 | 13-13/16 | 21 | 23-1/4 | 43-5/8 | 21-9/16 | 17-3/8 | 11/16 | 22-1/2 | 7-1/2 | 18-1/2 | 14-1/2 | 8-3/4 | 2-7/8 | 3-7/8 | 6-7/16 | 31 |
| 150, 175 | 38-1/8 | 20-1/8 | 23 | 16 | 30-9/16 | 60-1/8 | 35-3/8 | 25-5/8 | 1-5/16 | 24-1/2 | 3-7/8 | 13-1/2 | 8-1/2 | 5-7/16 | 4-1/4 | 6-1/2 | 8-1/4 | 42 |
| 200 | 38-1/8 | 20-1/8 | 23 | 16 | 30-9/16 | 60-1/8 | 35-3/8 | 25-5/8 | 1-5/16 | 24-1/2 | 3-7/8 | 14-9/16 | 9-9/16 | 5-7/16 | 4-5/16 | 6-1/2 | 8-5/16 | 42 |
| 225, 250 | 38-1/8 | 26-1/8 | 23 | 22 | 39-5/8 | 63-7/16 | 35-3/8 | 25-5/8 | 1-5/16 | 24-1/2 | 5-7/8 | 18-1/16 | 13-1/16 | 9 | 4-5/16 | 6-1/2 | 8-5/16 | 42 |
| 300, 350, 400 | 40-7/8 | 34-1/8 | 23 | 30 | 42-5/8 | 63-7/16 | 35-3/8 | 27-5/8 | 1-5/16 | 23-1/2 | 3-7/8 | 22-1/16 | 17-1/16 | 11-13/16 | 4-1/2 | 7-1/4 | 8-1/2 | 42 |


Model UDBP Dimensions (mm ± 2)

| Size | A | B | C | D | E* | F | G | H** | J | K** | L | M | N | P | Q | R | S | T |
|---------------|------|-----|-----|-----|------|------|-----|-----|----|-----|-----|-----|-----|-----|-----|-----|-----|------|
| 30, 45 | 676 | 308 | 351 | 254 | 416 | 918 | 548 | 441 | 17 | 572 | 165 | 233 | 132 | 68 | 73 | 98 | 165 | 787 |
| 60 | 676 | 384 | 351 | 330 | 454 | 918 | 548 | 441 | 17 | 572 | 165 | 302 | 200 | 140 | 73 | 98 | 165 | 787 |
| 75 | 676 | 384 | 351 | 330 | 454 | 918 | 548 | 441 | 17 | 572 | 140 | 302 | 200 | 140 | 73 | 98 | 165 | 787 |
| 100 | 676 | 587 | 351 | 533 | 591 | 1108 | 548 | 441 | 17 | 572 | 216 | 470 | 368 | 222 | 73 | 98 | 164 | 787 |
| 125 | 676 | 587 | 351 | 533 | 594 | 1108 | 548 | 441 | 17 | 572 | 191 | 470 | 368 | 222 | 73 | 98 | 164 | 787 |
| 150, 175 | 968 | 511 | 584 | 406 | 776 | 1527 | 899 | 651 | 33 | 622 | 98 | 343 | 216 | 138 | 108 | 165 | 210 | 1067 |
| 200 | 968 | 511 | 584 | 406 | 776 | 1527 | 899 | 651 | 33 | 622 | 98 | 370 | 243 | 138 | 110 | 165 | 211 | 1067 |
| 225, 250 | 968 | 664 | 584 | 559 | 1006 | 1611 | 899 | 651 | 33 | 622 | 149 | 459 | 332 | 229 | 110 | 165 | 211 | 1067 |
| 300, 350, 400 | 1038 | 867 | 584 | 762 | 1083 | 1611 | 899 | 702 | 33 | 597 | 98 | 560 | 433 | 300 | 114 | 184 | 216 | 1067 |

4.0 Clearances and Dimensions (cont'd)

4.2. Dimensions (cont'd)

FIGURE 6 - Model UDBS, Separated Combustion Fan Model



NOTES: *Sizes 150-400 - Dimension E varies with motor selection and belt adjustment.

**Dimensions H and K are the heater suspension points.

Model UDBS Dimensions (inches $\pm 1/16$)

| Size | A | B | C | D | E* | F | G | H** | J | K** | L | M | N | P | Q | R | S | T |
|---------------|--------|--------|----------|----|---------|---------|---------|--------|--------|--------|-------|---------|---------|----------|--------|-------|--------|----|
| 30, 45 | 26-5/8 | 12-1/8 | 13-13/16 | 10 | 16-3/8 | 36-1/8 | 21-9/16 | 17-3/8 | 11/16 | 22-1/2 | 6-1/2 | 9-3/16 | 5-3/16 | 2-11/16 | 2-7/8 | 3-7/8 | 6-1/2 | 31 |
| 60 | 26-5/8 | 15-1/8 | 13-13/16 | 13 | 17-7/8 | 36-1/8 | 21-9/16 | 17-3/8 | 11/16 | 22-1/2 | 6-1/2 | 11-7/8 | 7-7/8 | 5-1/2 | 2-7/8 | 3-7/8 | 6-1/2 | 31 |
| 75 | 26-5/8 | 15-1/8 | 13-13/16 | 13 | 17-7/8 | 36-1/8 | 21-9/16 | 17-3/8 | 11/16 | 22-1/2 | 5-1/2 | 11-7/8 | 7-7/8 | 5-1/2 | 2-7/8 | 3-7/8 | 6-1/2 | 31 |
| 100 | 26-5/8 | 23-1/8 | 13-13/16 | 21 | 23-1/4 | 43-5/8 | 21-9/16 | 17-3/8 | 11/16 | 22-1/2 | 8-1/2 | 18-1/2 | 14-1/2 | 8-3/4 | 2-7/8 | 3-7/8 | 6-7/16 | 31 |
| 125 | 26-5/8 | 23-1/8 | 13-13/16 | 21 | 23-1/4 | 43-5/8 | 21-9/16 | 17-3/8 | 11/16 | 22-1/2 | 7-1/2 | 18-1/2 | 14-1/2 | 8-3/4 | 2-7/8 | 3-7/8 | 6-7/16 | 31 |
| 150, 175 | 38-1/8 | 20-1/8 | 23 | 16 | 30-9/16 | 60-1/8 | 35-3/8 | 25-5/8 | 1-5/16 | 24-1/2 | 3-7/8 | 13-1/2 | 8-1/2 | 5-7/16 | 4-1/4 | 6-1/2 | 8-1/4 | 42 |
| 200 | 38-1/8 | 20-1/8 | 23 | 16 | 30-9/16 | 60-1/8 | 35-3/8 | 25-5/8 | 1-5/16 | 24-1/2 | 3-7/8 | 14-9/16 | 9-9/16 | 5-7/16 | 4-5/16 | 6-1/2 | 8-5/16 | 42 |
| 225, 250 | 38-1/8 | 26-1/8 | 23 | 22 | 39-5/8 | 63-7/16 | 35-3/8 | 25-5/8 | 1-5/16 | 24-1/2 | 5-7/8 | 18-1/16 | 13-1/16 | 9 | 4-5/16 | 6-1/2 | 8-5/16 | 42 |
| 300, 350, 400 | 40-7/8 | 34-1/8 | 23 | 30 | 42-5/8 | 63-7/16 | 35-3/8 | 27-5/8 | 1-5/16 | 23-1/2 | 3-7/8 | 22-1/16 | 17-1/16 | 11-13/16 | 4-1/2 | 7-1/4 | 8-1/2 | 42 |

Model UDBS Dimensions (mm ± 2)

| Size | A | B | C | D | E* | F | G | H** | J | K** | L | M | N | P | Q | R | S | T |
|---------------|------|-----|-----|-----|------|------|-----|-----|----|-----|-----|-----|-----|-----|-----|-----|-----|------|
| 30, 45 | 676 | 511 | 351 | 254 | 416 | 918 | 548 | 441 | 17 | 572 | 165 | 233 | 132 | 68 | 73 | 98 | 165 | 787 |
| 60 | 676 | 384 | 351 | 330 | 454 | 918 | 548 | 441 | 17 | 572 | 165 | 302 | 200 | 140 | 73 | 98 | 165 | 787 |
| 75 | 676 | 384 | 351 | 330 | 454 | 918 | 548 | 441 | 17 | 572 | 140 | 302 | 200 | 140 | 73 | 98 | 165 | 787 |
| 100 | 676 | 587 | 351 | 533 | 591 | 1108 | 548 | 441 | 17 | 572 | 216 | 470 | 368 | 222 | 73 | 98 | 164 | 787 |
| 125 | 676 | 587 | 351 | 533 | 594 | 1108 | 548 | 441 | 17 | 572 | 191 | 470 | 368 | 222 | 73 | 98 | 164 | 787 |
| 150, 175 | 968 | 511 | 584 | 406 | 776 | 1527 | 899 | 651 | 33 | 622 | 98 | 343 | 216 | 138 | 108 | 165 | 210 | 1067 |
| 200 | 968 | 511 | 584 | 406 | 776 | 1527 | 899 | 651 | 33 | 622 | 98 | 370 | 243 | 138 | 110 | 165 | 211 | 1067 |
| 225, 250 | 968 | 664 | 584 | 559 | 1006 | 1611 | 899 | 651 | 33 | 622 | 149 | 459 | 332 | 229 | 110 | 165 | 211 | 1067 |
| 300, 350, 400 | 1038 | 867 | 584 | 762 | 1083 | 1611 | 899 | 702 | 33 | 597 | 98 | 560 | 433 | 300 | 114 | 184 | 216 | 1067 |

5.0 Hanging the Heater

5.1 Weights

Before suspending the heater, check the supporting structure to be used to verify that it has sufficient load-carrying capacity to support the weight of the unit.

Model UDBP

| Size | 30 | 45 | 60 | 75 | 100 | 125 | 150 | 175, 200 | 225 | 250 | 300 | 350 | 400 |
|------|----|----|----|----|-----|-----|-----|----------|-----|-----|-----|-----|-----|
| lbs | 72 | 77 | 89 | 94 | 131 | 136 | 255 | 275 | 320 | 335 | 375 | 410 | 425 |
| kg | 33 | 35 | 40 | 43 | 59 | 62 | 116 | 125 | 145 | 152 | 170 | 186 | 193 |

Model UDBS

| Size | 30 | 45 | 60 | 75 | 100 | 125 | 150 | 175, 200 | 225 | 250 | 300 | 350 | 400 |
|------|----|----|----|----|-----|-----|-----|----------|-----|-----|-----|-----|-----|
| lbs | 72 | 77 | 89 | 94 | 131 | 136 | 255 | 275 | 320 | 335 | 375 | 410 | 425 |
| kg | 33 | 35 | 40 | 43 | 59 | 62 | 116 | 125 | 145 | 152 | 170 | 186 | 193 |

WARNINGS

Check the supporting structure to be used to verify that it has sufficient load carrying capacity to support the weight of the unit. Suspend the heater only from the threaded nut retainers or with a manufacturer provided kit. Do NOT suspend from the heater cabinet.

5.2 Lifting and Suspending

When the heater is lifted for suspension, support the bottom of the heater with plywood or other appropriately placed material. If the bottom is not supported, damage could occur. Before hanging, verify that any screws used for holding shipping brackets were re-installed in the cabinet.

NOTE: If installation of a Model UDBP or UDBS Size 30-125 includes an optional step-down transformer (Option CG2 or CG4), attaching the transformer bracket is part of the suspension procedure. Follow the instructions shipped with the transformer.

When the heater is lifted for suspension, support the bottom of the heater with plywood or other appropriately placed material. If the bottom is not supported, damage could occur. Before hanging, verify that all screws used for holding shipping brackets were re-installed in the cabinet.

Models UDBP and UDBS are equipped for four-point suspension. See Dimensions in Paragraph 4.2 and the illustration in **FIGURE 5 or 6.**


WARNING

Unit must be level for proper operation. Do not place or add additional weight to the suspended heater. Hazard Levels, page 2.

FIGURE 7 - Suspending the Heater with Threaded Rods

Be sure the threaded hanger rods are locked to the hanger bars as illustrated. Hanger rods and hardware are field supplied.

Recommended maximum hanger rod length is 6 feet (1.8M).




5.0 Hanging the Heater (cont'd)

If ordered with swivel connectors for 1" pipe, Option CK10, use field-supplied hardware to attach the swivels at the suspension holes. Suspend with 1" pipe. See **FIGURE 8**.

FIGURE 8 - Swivel Connectors to Suspend the Heater from 1" Pipe, Option CK10

Be sure the threaded swivel connectors are locked to the hanger bars as illustrated.



6.0 Mechanical

6.1 Gas Piping and Pressures

6.1.1 Gas Supply and Connections

WARNING

This appliance is equipped for a maximum gas supply pressure of 1/2 psi, 3.5 kPa, or 14 inches water column. Supply pressure greater than 1/2 psi requires installation of an additional lockup-type service regulator external to the unit.

WARNING: PRESSURE TESTING SUPPLY PIPING

Test Pressures Above 1/2 PSI: Disconnect the heater and manual valve from the gas supply line which is to be tested. Cap or plug the supply line.

Test Pressures Below 1/2 PSI: Before testing, close the manual valve on the heater.

All piping must be in accordance with requirements outlined in the National Fuel Gas Code ANSI/Z223.1a (latest edition) or CSA-B149.1 and B149.2 (See Paragraph 2). Gas supply piping installation should conform with good practice and with local codes. Support gas piping with pipe hangers, metal strapping, or other suitable material; do not rely on the heater to support the gas pipe.

The heater is orificed for operation with natural gas having a heating value of 1000 (\pm 50) BTU per cubic ft or propane gas with a heating value of 2500 (\pm 100) BTU per cubic ft. If the gas at the installation does not meet these specifications, consult the factory for proper orificing.

Pipe joint compounds (pipe dope) shall be resistant to the action of liquefied petroleum gas or any other chemical constituents of the gas being supplied.

Install a ground joint union and manual shutoff valve upstream of the unit control system, as shown in **FIGURE 9**. Installation of a trap with a minimum 3" (76mm) drip leg is required.

The unit is equipped with a nipple that extends outside the cabinet. The gas connection is either 1/2" or 3/4".

Leak-test all connections by brushing on a leak-detecting solution.

WARNING

All components of a gas supply system must be leak tested prior to placing equipment in service. NEVER TEST FOR LEAKS WITH AN OPEN FLAME. Failure to comply could result in personal injury, property damage, or death.

Sizing Gas Supply Line


| Capacity of Piping | | | | | | | | | | | | |
|--|------------------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|---------|
| Cubic Feet per Hour based on 0.3" w.c. Pressure Drop | | | | | | | | | | | | |
| Specific Gravity for Natural Gas -- 0.6 (Natural Gas -- 1000 BTU/Cubic Ft) | | | | | | | | | | | | |
| Specific Gravity for Propane Gas -- 1.6 (Propane Gas -- 2550 BTU/Cubic Ft) | | | | | | | | | | | | |
| Length of Pipe | Diameter of Pipe | | | | | | | | | | | |
| | 1/2" | | 3/4" | | 1" | | 1-1/4" | | 1-1/2" | | 2" | |
| | Natural | Propane | Natural | Propane | Natural | Propane | Natural | Propane | Natural | Propane | Natural | Propane |
| 20' | 92 | 56 | 190 | 116 | 350 | 214 | 730 | 445 | 1100 | 671 | 2100 | 1281 |
| 30' | 73 | 45 | 152 | 93 | 285 | 174 | 590 | 360 | 890 | 543 | 1650 | 1007 |
| 40' | 63 | 38 | 130 | 79 | 245 | 149 | 500 | 305 | 760 | 464 | 1450 | 885 |
| 50' | 56 | 34 | 115 | 70 | 215 | 131 | 440 | 268 | 670 | 409 | 1270 | 775 |
| 60' | 50 | 31 | 105 | 64 | 195 | 119 | 400 | 244 | 610 | 372 | 1105 | 674 |
| 70' | 46 | 28 | 96 | 59 | 180 | 110 | 370 | 226 | 560 | 342 | 1050 | 641 |
| 80' | 43 | 26 | 90 | 55 | 170 | 104 | 350 | 214 | 530 | 323 | 990 | 604 |
| 90' | 40 | 24 | 84 | 51 | 160 | 98 | 320 | 195 | 490 | 299 | 930 | 567 |
| 100' | 38 | 23 | 79 | 48 | 150 | 92 | 305 | 186 | 460 | 281 | 870 | 531 |
| 125' | 34 | 21 | 72 | 44 | 130 | 79 | 275 | 168 | 410 | 250 | 780 | 476 |
| 150' | 31 | 19 | 64 | 39 | 120 | 73 | 250 | 153 | 380 | 232 | 710 | 433 |
| 175' | 28 | 17 | 59 | 36 | 110 | 67 | 225 | 137 | 350 | 214 | 650 | 397 |
| 200' | 26 | 16 | 55 | 34 | 100 | 61 | 210 | 128 | 320 | 195 | 610 | 372 |
| Note: When sizing supply lines, consider possibilities of future expansion and increased requirements. | | | | | | | | | | | | |
| Refer to National Fuel Gas Code for additional information on line sizing. | | | | | | | | | | | | |

Gas Connection Size

| Gas Connection (inches) | | |
|---|---------|---------|
| Size | Natural | Propane |
| 30, 45, 60, 75, 100, 125, 150, 175, 200 | 1/2 | 1/2 |
| 225, 250, 300, 350, 400 | 3/4 | 3/4 |

FIGURE 9 - Gas connection is at the pipe nipple that extends outside the cabinet.

Illustration shows both a vertical and horizontal gas supply; requirements are the same.



6.1.2 Valve Outlet or Orifice Pressure Setting

NOTE: Gas Conversion Kits are available for changing from propane gas to natural gas or natural gas to propane gas. A factory-authorized conversion kit **MUST** be used.

Measuring valve outlet gas pressure cannot be done until the heater is in operation. It is included in the steps of the "Check-Test-Start" procedure in Paragraph 9. The following warnings and instructions apply.

WARNING

Valve outlet gas pressure must never exceed 3.5" w.c. for natural gas and 10" w.c. for propane gas.

For Natural Gas: When the heater leaves the factory, the combination gas valve is set so that the valve outlet gas pressure for a single-stage valve or high fire of a two-stage valve is regulated to 3.5" w.c. Low fire on a two-stage valve is set to 1.8" w.c. Inlet supply pressure to the valve for natural gas must be a minimum of 5" w.c. or as noted on the rating plate and a maximum of 14" w.c.

For Propane Gas: When the heater leaves the factory, the combination gas valve is set so that the valve outlet gas pressure for a single-stage valve or high fire of a two-stage valve is regulated to 10" w.c. Low fire on a two-stage valve is set to 5.0" w.c. Inlet supply pressure to the valve for propane gas must be a minimum of 11" w.c. and a maximum of 14" w.c.

Before attempting to measure or adjust valve outlet gas pressure, the inlet supply pressure *must* be within the specified range both when the heater is in operation and

6.0 Mechanical (cont'd)

6.1 Gas Piping and Pressures (cont'd)

**Check Valve Outlet
Pressure (can only
be done after heater
is operating)**

6.1.2 Valve Outlet or Orifice Pressure Setting (cont'd)


on standby. Incorrect inlet pressure could cause excessive valve outlet gas pressure immediately or at some future time. If natural gas supply pressure is too high, install a regulator in the supply line before it reaches the heater. If natural gas supply pressure is too low, contact your gas supplier.

Instructions

NOTE: If operating at high altitude, outlet pressure requires adjustment. Follow the instructions in Paragraph 6.1.3 below.

- 1) Locate the 1/8" output pressure tap on the valve (See **FIGURE 10**). With the manual valve turned off to prevent flow to the gas valve, connect a manometer to the 1/8" pipe outlet pressure tap in the valve. NOTE: A manometer (fluid-filled gauge) is recommended rather than a spring type gauge due to the difficulty of maintaining calibration of a spring type gauge.

FIGURE 10 - Top View of Valves showing Outlet Pressure Tap and Adjustment Locations



CAUTION: DO NOT bottom out the gas valve regulator adjusting screw. This can result in unregulated manifold pressure causing excess overfire and heat exchanger failure.

- 2) Open the manual valve and operate the heater. (NOTE: On Model UDBS, depress and hold the door safety switch.) Measure the outlet pressure of the gas valve. To measure low-stage pressure on a unit equipped with a two-stage valve, disconnect the wire from the "HI" terminal on the valve. (Be sure to reconnect the wire.) Normally when operating at sea level, adjustments should not be necessary to the factory setting. (For high altitude settings, see next paragraph.) If adjustment is necessary, remove the cap from the adjustment screw(s). Set pressure to correct settings by turning the regulator screw IN (clockwise) to increase pressure. Turn regulator screw OUT (counterclockwise) to decrease pressure.

6.1.3 Derate by Valve Outlet Pressure Adjustment for High Altitude Operation

**This adjustment
can only be done
after the heater is in
operation. High altitude
adjustment is included
in the startup Steps.**

NOTE: If elevation is above 6000 ft (1830M), a high altitude pressure switch is required; see Paragraph 3.2.1.

Instructions for High Altitude Derate

1. Determine the required valve outlet pressure for the elevation where the heater will be operating. If unsure of the elevation, contact the local gas supplier.

Valve Outlet Pressure Settings by Elevation

| Manifold Pressure Settings by Altitude for the UNITED STATES | | | | | |
|--|-----------|--------------------------------------|--------------------|--------------------------------------|--------------------|
| Altitude | | Natural Gas (inches w.c.) | | Propane Gas (inches w.c.) | |
| Feet | Meters | Single-Stage and Two-Stage High Fire | Two-Stage Low Fire | Single-Stage and Two-Stage High Fire | Two-Stage Low Fire |
| 0-2000 | 0-610 | 3.5 | 1.8 | 10.0 | 5.0 |
| 2001-3000 | 611-915 | 3.1 | 1.6 | 8.8 | 4.4 |
| 3001-4000 | 916-1220 | 3.0 | 1.5 | 8.5 | 4.2 |
| 4001-5000 | 1221-1525 | 2.8 | 1.5 | 8.1 | 4.1 |
| 5001-6000 | 1526-1830 | 2.7 | 1.4 | 7.7 | 3.9 |
| 6001-7000 | 1831-2135 | 2.6 | 1.3 | 7.4 | 3.7 |
| 7001-8000 | 2136-2440 | 2.5 | 1.3 | 7.1 | 3.5 |
| 8001-9000 | 2441-2745 | 2.4 | 1.2 | 6.7 | 3.4 |
| 9001-10000 | 2746-3045 | 2.3 | 1.2 | 6.7 | 3.4 |

| Manifold Pressure Settings by Altitude for CANADA | | | | | |
|---|----------|--------------------------------------|--------------------|--------------------------------------|--------------------|
| Altitude | | Natural Gas (inches w.c.) | | Propane Gas (inches w.c.) | |
| Feet | Meters | Single-Stage and Two-Stage High Fire | Two-Stage Low Fire | Single-Stage and Two-Stage High Fire | Two-Stage Low Fire |
| 0-2000 | 0-610 | 3.5 | 1.8 | 10.0 | 5.0 |
| 2001-4500 | 611-1373 | 2.8 | 1.5 | 8.1 | 4.1 |

- Locate the 1/8" output pressure tap on the valve (See **FIGURE 10**, page 14). Turn the knob or switch on the top of the valve to "OFF". Connect a manometer to the 1/8" pipe outlet pressure tap in the valve. Use a water column manometer that is readable to the nearest tenth of an inch.
- Single-Stage and Two-Stage High Fire** - Turn the knob or move the switch on the top of the valve to "ON". Remove the cap from the pressure adjusting screw and adjust the gas train pressure to the pressure selected from the table above. Adjust pressure by turning the regulator screw IN (clockwise) to increase pressure or OUT (counterclockwise) to decrease pressure.
Two-Stage Low Fire - Disconnect the wire from the "HI" terminal on the gas valve and check the low fire pressure. Turn the regulator screw to adjust the low fire outlet pressure to the "Low Fire" pressure selected from the table. Re-connect the wire to the gas valve.
- Turn up the thermostat. (NOTE: On Model UDBS, depress and hold the door safety switch.) Cycle the burner once or twice to properly seat the adjustment spring in the valve.
Re-check the pressure(s). When the outlet pressure is right for the installation, remove the manometer and replace the cap.
Check for leak at the pressure tap fitting.
- With the heater operating determine that the inlet pressure to the heater for natural gas is between 5 and 13.5 inches w.c. and for propane between 10 and 13.5 inches w.c. Take this reading as close as possible to the heater (Heaters are equipped with gas valves that have an inlet pressure tap.) If the inlet pressure is not within the specified range, the inlet pressure must be corrected and Steps 3 and 4 repeated.
- Find the High Altitude Adjustment label in the plastic bag that contained these instructions. Using a permanent marker, fill-in the appropriate information from the tables below. Select a location for the label on the outside of the heater access panel so that it will be conspicuous to anyone operating or servicing the unit. Be sure the surface is clean and dry and adhere the label.

High Altitude Capacity Changes

The input and/or the capacity of the heater changes with the derate. The tables below list inputs and capacities at altitudes from sea level to 10,000 ft (3045M).

| BTUH Inputs and Capacities by Altitude in the UNITED STATES for Model UDBP and Model UDBS | | | | | | | | | | | | | |
|---|-----------|--------------|-------------------------|---------------|--------------|-------------------------|---------------|--------------|-------------------------|---------------|--------------|-------------------------|---------------|
| ALTITUDE | | Normal Input | Thermal Output Capacity | Minimum Input | Normal Input | Thermal Output Capacity | Minimum Input | Normal Input | Thermal Output Capacity | Minimum Input | Normal Input | Thermal Output Capacity | Minimum Input |
| Feet | Meters | Size 30 | | | Size 45 | | | Size 60 | | | Size 75 | | |
| 0-2000 | 0-610 | 30000 | 24600 | 30000 | 45000 | 37350 | 45000 | 60000 | 49800 | 42000 | 75000 | 62250 | 52500 |
| 2001-3000 | 611-915 | 28200 | 23124 | 28200 | 42300 | 35109 | 42300 | 56400 | 46812 | 39480 | 70500 | 58515 | 49350 |
| 3001-4000 | 916-1220 | 27600 | 22632 | 27600 | 41400 | 34362 | 41400 | 55200 | 45816 | 38640 | 69000 | 57270 | 48300 |
| 4001-5000 | 1221-1525 | 27000 | 22140 | 27000 | 40500 | 33615 | 40500 | 54000 | 44820 | 37800 | 67500 | 56025 | 47250 |
| 5001-6000 | 1526-1830 | 26400 | 21648 | 26400 | 39600 | 32868 | 39600 | 52800 | 43824 | 36960 | 66000 | 54780 | 46200 |
| 6001-7000 | 1831-2135 | 25800 | 21156 | 25800 | 38700 | 32121 | 38700 | 51600 | 42828 | 36120 | 64500 | 53535 | 45150 |
| 7001-8000 | 2136-2440 | 25200 | 20664 | 25200 | 37800 | 31374 | 37800 | 50400 | 41832 | 35280 | 63000 | 52290 | 44100 |
| 8001-9000 | 2441-2745 | 24600 | 20172 | 24600 | 36900 | 30627 | 36900 | 49200 | 40836 | 34440 | 61500 | 51045 | 43050 |
| 9001-10000 | 2746-3045 | 24000 | 19680 | 24000 | 36000 | 29880 | 36000 | 48000 | 39840 | 33600 | 60000 | 49800 | 42000 |
| Feet | Meters | Size 100 | | | Size 125 | | | Size 150 | | | Size 175 | | |
| 0-2000 | 0-610 | 105000 | 88200 | 73500 | 120000 | 100800 | 84000 | 150000 | 124500 | 105000 | 175000 | 145250 | 122500 |
| 2001-3000 | 611-915 | 98700 | 82908 | 69090 | 112800 | 94752 | 78960 | 141000 | 117030 | 98700 | 164500 | 136535 | 115150 |
| 3001-4000 | 916-1220 | 96600 | 81144 | 67620 | 110400 | 92736 | 77280 | 138000 | 114540 | 96600 | 161000 | 133630 | 112700 |
| 4001-5000 | 1221-1525 | 94500 | 79380 | 66150 | 108000 | 90720 | 75600 | 135000 | 112050 | 94500 | 157500 | 130725 | 110250 |
| 5001-6000 | 1526-1830 | 92400 | 77616 | 64680 | 105600 | 88704 | 73920 | 132000 | 109560 | 92400 | 154000 | 127820 | 107800 |
| 6001-7000 | 1831-2135 | 90300 | 75852 | 63210 | 103200 | 86888 | 72240 | 129000 | 107070 | 90300 | 150500 | 124915 | 105350 |
| 7001-8000 | 2136-2440 | 88200 | 74088 | 61740 | 100800 | 84672 | 70560 | 126000 | 104580 | 88200 | 147000 | 122010 | 102900 |
| 8001-9000 | 2441-2745 | 86100 | 72324 | 60270 | 98400 | 82656 | 68880 | 123000 | 102090 | 86100 | 143500 | 119105 | 100450 |
| 9001-10000 | 2746-3045 | 84000 | 70560 | 58800 | 96000 | 80640 | 67200 | 120000 | 99600 | 84000 | 140000 | 116200 | 98000 |

6.0 Mechanical (cont'd)

High Altitude Capacity Changes (cont'd)

6.1 Gas Piping and Pressures (cont'd)

6.1.3 Derate by Valve Outlet Pressure Adjustment for High Altitude Operation (cont'd)

| BTUH Inputs and Capacities by Altitude in the UNITED STATES for Model UDBP and Model UDBS (cont'd) | | | | | | | | | | | | |
|--|-----------|--------------|-------------------------|---------------|--------------|-------------------------|---------------|--------------|-------------------------|---------------|--------------|-------------------------|
| ALTITUDE | | Normal Input | Thermal Output Capacity | Minimum Input | Normal Input | Thermal Output Capacity | Minimum Input | Normal Input | Thermal Output Capacity | Minimum Input | Normal Input | Thermal Output Capacity |
| Feet | Meters | Size 200 | | | Size 225 | | | Size 250 | | | Size 300 | |
| 0-2000 | 0-610 | 200000 | 166000 | 140000 | 225000 | 186750 | 157500 | 250000 | 207500 | 175000 | 300000 | 249000 |
| 2001-3000 | 611-915 | 188000 | 156040 | 131600 | 211500 | 175545 | 148050 | 235000 | 195050 | 164500 | 282000 | 234060 |
| 3001-4000 | 916-1220 | 184000 | 152720 | 128800 | 207000 | 171810 | 144900 | 230000 | 190900 | 161000 | 276000 | 229080 |
| 4001-5000 | 1221-1525 | 180000 | 149400 | 126000 | 202500 | 168075 | 141750 | 225000 | 186750 | 157500 | 270000 | 224100 |
| 5001-6000 | 1526-1830 | 176000 | 146080 | 123200 | 198000 | 164340 | 138600 | 220000 | 182600 | 154000 | 264000 | 219120 |
| 6001-7000 | 1831-2135 | 172000 | 142760 | 120400 | 193500 | 160605 | 135450 | 215000 | 178450 | 150500 | 258000 | 214140 |
| 7001-8000 | 2136-2440 | 168000 | 139440 | 117600 | 189000 | 156870 | 132300 | 210000 | 174300 | 147000 | 252000 | 209160 |
| 8001-9000 | 2441-2745 | 164000 | 136120 | 114800 | 184500 | 153135 | 129150 | 205000 | 170150 | 143500 | 246000 | 204180 |
| 9001-10000 | 2746-3045 | 160000 | 132800 | 112000 | 180000 | 149400 | 126000 | 200000 | 166000 | 140000 | 240000 | 199200 |
| Feet | Meters | Size 350 | | | Size 400 | | | | | | | |
| 0-2000 | 0-610 | 350000 | 290500 | 245000 | 400000 | 332000 | 280000 | | | | | |
| 2001-3000 | 611-915 | 329000 | 273070 | 230300 | 376000 | 312080 | 263200 | | | | | |
| 3001-4000 | 916-1220 | 322000 | 267260 | 225400 | 368000 | 305440 | 257600 | | | | | |
| 4001-5000 | 1221-1525 | 315000 | 261450 | 220500 | 360000 | 298800 | 252000 | | | | | |
| 5001-6000 | 1526-1830 | 308000 | 255640 | 215600 | 352000 | 292160 | 246400 | | | | | |
| 6001-7000 | 1831-2135 | 301000 | 249830 | 210700 | 344000 | 285520 | 240800 | | | | | |
| 7001-8000 | 2136-2440 | 294000 | 244020 | 205800 | 336000 | 278880 | 235200 | | | | | |
| 8001-9000 | 2441-2745 | 287000 | 238210 | 200900 | 328000 | 272240 | 229600 | | | | | |
| 9001-10000 | 2746-3045 | 280000 | 232400 | 196000 | 320000 | 265600 | 224000 | | | | | |

| BTUH Inputs and Capacities by Altitude in CANADA for Models UDBP and UDBS | | | | | | | | | | | | |
|---|----------|--------------|-------------------------|---------------|--------------|-------------------------|---------------|--------------|-------------------------|---------------|--------------|-------------------------|
| ALTITUDE | | Normal Input | Thermal Output Capacity | Minimum Input | Normal Input | Thermal Output Capacity | Minimum Input | Normal Input | Thermal Output Capacity | Minimum Input | Normal Input | Thermal Output Capacity |
| Feet | Meters | Size 30 | | | Size 45 | | | Size 60 | | | Size 75 | |
| 0-2000 | 0-610 | 30000 | 24600 | 30000 | 45000 | 37350 | 45000 | 60000 | 49800 | 42000 | 75000 | 62250 |
| 2001-4500 | 611-1373 | 27000 | 22140 | 27000 | 40500 | 33615 | 40500 | 54000 | 44820 | 37800 | 67500 | 56025 |
| Feet | Meters | Size 100 | | | Size 125 | | | Size 150 | | | Size 175 | |
| 0-2000 | 0-610 | 105000 | 88200 | 73500 | 120000 | 100800 | 84000 | 150000 | 124500 | 105000 | 175000 | 145250 |
| 2001-4500 | 611-1373 | 94500 | 79380 | 66150 | 108000 | 90720 | 75600 | 135000 | 113400 | 94500 | 157500 | 132300 |
| Feet | Meters | Size 200 | | | Size 225 | | | Size 250 | | | Size 300 | |
| 0-2000 | 0-610 | 200000 | 166000 | 140000 | 225000 | 186750 | 157500 | 250000 | 207500 | 175000 | 300000 | 249000 |
| 2001-4500 | 611-1373 | 180000 | 151200 | 126000 | 202500 | 170100 | 141750 | 225000 | 189000 | 157500 | 270000 | 226800 |
| Feet | Meters | Size 350 | | | Size 400 | | | | | | | |
| 0-2000 | 0-610 | 350000 | 290500 | 245000 | 400000 | 332000 | 280000 | | | | | |
| 2001-4500 | 611-1373 | 315000 | 264600 | 220500 | 360000 | 302400 | 252000 | | | | | |

6.2 Combustion Air - Models UDBP

(Note: For Model UDBS, see Venting Manual for combustion air requirements.)

Combustion Air Requirements for a Heater Located in a Confined Space - applies to Model UDBP

This heater must be supplied with the air that enters into the combustion process and is then vented to the outdoors. Sufficient air must enter the equipment location to replace that exhausted through the heater vent system. In the past, the infiltration of outside air assumed in heat loss calculations (one air change per hour) was assumed to be sufficient. However, current construction methods using more insulation, vapor barriers, tighter fitting and gasketed doors and windows, weather-stripping, and/or mechanical exhaust fans may now require the introduction of outside air through wall openings or ducts.

The requirements for combustion and ventilation air depend upon whether the unit is located in a confined or unconfined space. An "unconfined space" is defined as a space whose volume is not less than 50 cubic feet per 1000 BTUH of the installed appliance. **Under ALL conditions**, enough air must be provided to ensure there will not be a negative pressure condition within the equipment room or space.

WARNING

Model UDBP power-vented unit heaters are designed to take combustion air from the space in which the unit is installed and are not designed for connection to outside combustion air intake ducts. Connecting outside air ducts voids the warranty and could cause hazardous operation. See Hazard Levels, page 2.


Do not install a unit in a confined space without providing wall openings leading to and from the space. Provide openings near the floor and ceiling for ventilation and air for combustion as shown in **FIGURE 11**, depending on the combustion air source as noted in Items 1, 2, and 3 below.

Add total BTUH of all appliances in the confined space and divide by figures below for square inch free area size of each (top and bottom) opening.

FIGURE 11 - Definition of Confined Space and Required Openings for Combustion Air

Confined Space:

A space whose volume is less than 50 cubic feet per 1000 BTUH of the installed appliance input rating



- 1. Air from inside the building** -- openings 1 square inch free area per 1000 BTUH. Never less than 100 square inches of free area for each opening. See (1) in **FIGURE 11**.
- 2. Air from outside through duct** -- openings 1 square inch free area per 2000 BTUH. See (2) in **FIGURE 11**.
- 3. Air direct from outside** -- openings 1 square inch free area per 4000 BTUH. See (3) in **FIGURE 11**.

NOTE: For further details on supplying combustion air to a confined space, see the National Fuel Gas Code ANSI Z223.1a (latest edition).

6.3 Unit Discharge

Depending on how the heater was ordered, it is shipped with either horizontal louvers or a factory-installed duct flange (Option AX4).

Shipped-separate, field-installed discharge options include a duct flange, vertical louvers in addition to the horizontal louvers, a choice of one or two downturn nozzle sections available with and without vertical louvers; and a polytube adapter for greenhouse or similar applications. Follow the instructions included with the field-installed option package to attach the parts to the heater.

Dimensions of the field-installed downturn nozzles are shown in Paragraph 3.2.

If equipped with a duct flange or a polytube adapter, field-supplied metal or polytube ductwork will need to be installed. Duct flange dimensions are shown in **FIGURE 12**. Polytube adapter dimensions and polytube requirements are shown in **FIGURE 13**.

FIGURE 12 - Duct Flange Dimensions





FIGURE 13 - Polytube Adapter Dimensions and Requirements for field-supplied Polytube

| UDBP & UDBS | | A | B | C |
|---------------|--------|----------|--------|-----|
| 75 | inches | 16-15/16 | 10-3/8 | 9 |
| | mm | 430 | 264 | 229 |
| 100, 125 | inches | 17 | 10-3/8 | 9 |
| | mm | 432 | 264 | 229 |
| 150, 175, 200 | inches | 16-3/16 | 13-3/8 | 12 |
| | mm | 411 | 340 | 305 |
| 225, 250 | inches | 16-3/16 | 13-3/8 | 12 |
| | mm | 411 | 340 | 305 |
| 300, 350, 400 | inches | 16-3/16 | 13-3/8 | 12 |
| | mm | 411 | 340 | 305 |



6.0 Mechanical (cont'd)

6.3 Unit Discharge (cont'd)

FIGURE 13 (cont'd) - Requirements for field-supplied Polytube Duct

| Size | CFM at 60°F Temp Rise | Polytube Diameter (inches) | Approximate Free Area (square inches) | Suggested Hole Sizes and Locations by Length | | | | | |
|------|--------------------------|----------------------------------|---|--|--------------------|----------|----------|----------|----------|
| | | | | Polytube Holes | Length of Polytube | | | | |
| | | | | | 50 Ft | 75 Ft | 100 Ft | 125 Ft | 150 Ft |
| 75* | 960 | 18 | 115 | Quantity | 75 pairs | 75 pairs | 75 pairs | 75 pairs | 75 pairs |
| | | | | Diameter | 1" | 1" | 1" | 1" | 1" |
| | | | | Spacing | 8" | 12" | 16" | 20" | 24" |
| 100* | 1345 | 18 | 160 | Quantity | 48 pairs | 48 pairs | 48 pairs | 48 pairs | 48 pairs |
| | | | | Diameter | 1-1/2" | 1-1/2" | 1-1/2" | 1-1/2" | 1-1/2" |
| | | | | Spacing | 12-1/2" | 18-3/4" | 25" | 31-1/4" | 37-1/2" |
| 125* | 1540 | 18 | 185 | Quantity | 50 pairs | 50 pairs | 50 pairs | 50 pairs | 50 pairs |
| | | | | Diameter | 1-1/2" | 1-1/2" | 1-1/2" | 1-1/2" | 1-1/2" |
| | | | | Spacing | 12" | 18" | 24" | 30" | 36" |
| 150 | 1920 | 24 | 230 | Quantity | 40 pairs | 40 pairs | 40 pairs | 40 pairs | 45 pairs |
| | | | | Diameter | 2" | 2" | 2" | 2" | 1-7/8" |
| | | | | Spacing | 15" | 22-1/2" | 30" | 37-1/2" | 40" |
| 175 | 2240 | 24 | 270 | Quantity | 50 pairs | 50 pairs | 80 pairs | 80 pairs | 80 pairs |
| | | | | Diameter | 1-7/8" | 1-7/8" | 1-1/2" | 1-1/2" | 1-1/2" |
| | | | | Spacing | 12" | 18" | 15" | 18-3/4" | 22-1/2" |
| 200 | 2560 | 24 | 300 | Quantity | 50 pairs | 50 pairs | 50 pairs | 50 pairs | 50 pairs |
| | | | | Diameter | 2" | 2" | 2" | 2" | 2" |
| | | | | Spacing | 12" | 18" | 24" | 30" | 36" |
| 225 | 2880 | 24 | 340 | Quantity | 42 pairs | 42 pairs | 42 pairs | 42 pairs | 42 pairs |
| | | | | Diameter | 2-1/4" | 2-1/4" | 2-1/4" | 2-1/4" | 2-1/4" |
| | | | | Spacing | 14" | 21" | 28" | 35" | 42" |
| 250 | 3200 | 24 | 380 | Quantity | 50 pairs | 50 pairs | 50 pairs | 60 pairs | 60 pairs |
| | | | | Diameter | 2-1/4" | 2-1/4" | 2-1/4" | 2" | 2" |
| | | | | Spacing | 12" | 18" | 24" | 25" | 30" |
| 300 | 3840 | 24 | 460 | Quantity | 60 pairs | 60 pairs | 75 pairs | 75 pairs | 75 pairs |
| | | | | Diameter | 2-1/4" | 2-1/4" | 2" | 2" | 2" |
| | | | | Spacing | 10" | 15" | 16" | 20" | 24" |
| 350 | 4480 | 24 | 540 | Quantity | 50 pairs | 50 pairs | 50 pairs | 50 pairs | 50 pairs |
| | | | | Diameter | 2-1/2" | 2-1/2" | 2-1/2" | 2-1/2" | 2-1/2" |
| | | | | Spacing | 12" | 18" | 24" | 30" | 36" |
| 400 | 5120 | 24 | 600 | Quantity | 60 pairs | 60 pairs | 75 pairs | 75 pairs | 75 pairs |
| | | | | Diameter | 2-1/2" | 2-1/2" | 2-1/4" | 2-1/4" | 2-1/4" |
| | | | | Spacing | 10" | 15" | 16" | 20" | 24" |

6.4 Blowers, Belts, and Drives

6.4.1 Belt

Blower Model **Sizes 30-125** are equipped with a direct drive motor. Blower Model **Sizes 150-400** have an adjustable belt drive.

Size 150-400 units are equipped with Power Twist Plus blower belts. These belts are designed in link sections allowing for easy sizing and adjustment. The belt is sized at the factory for the proper tension. If the belt needs adjustment, the recommended method of adjusting the belt length is to count the number of links and remove one link for every 24. (A link is made up of two joining sections of belt. For easier removal of links, turn the belt inside out. But be sure to turn it back before installing.) The belt tension should be checked after the first 24 hours of running at full load and at regular maintenance inspections. Proper belt tension is important to the long life of the belt and motor.

6.4.2 Adjusting Blower Speed

The blower speed may be adjusted to achieve the desired outlet temperature, as long as the adjustment is within the temperature rise and the static pressure limits shown on the heater rating plate. **Direct drive motors** are factory set as indicated in the chart on page 19. **Belt drive motors** are factory set at the nominal temperature rise specified for that unit.

If the duct resistance is low, the blower may deliver too high an air volume; or if the heater is operated without ductwork, the blower may deliver excess air to overload the motor, causing the overload protector to cycle the motor. Reducing the blower speed will correct these conditions. If ductwork is added to an installation, it may be necessary to increase the blower speed. Decreasing blower speed will increase outlet temperature; increasing blower speed will decrease outlet temperature.

Sizes 30-125 with Direct Drive

Direct drive blower motors have multi-speed taps for speed adjustment. If your installation requires an adjustment of the blower speed, the motor may be re-wired to an alternate tap by following these instructions.

1. Turn off the gas and the electric power.
2. Remove the access panel to reveal the wiring connections.
3. Consult the wiring diagram on the heater and follow the chart below to choose the wire for the desired adjustment. The asterisk(*) indicates the factory-wired speed.

| Model Sizes | Speed | Use these Two Motor Wires |
|----------------------|---------|---------------------------|
| 30 and 45 | Low | Red and White |
| | *Medium | *Blue and White |
| | High | Black and White |
| 60, 75, 100, and 125 | Low | Red and White |
| | Medium | Blue and White |
| | *High | *Black and White |

4. Cut the crimped cap from the end of the wire that you intend to use and strip the insulation.
5. Disconnect the factory-wired connection. Re-wire using the newly stripped wire.
6. Put a wire connector on the end of the blower motor wire that was disconnected.
7. Replace the heater access panel and turn on the gas and the electric.

Sizes 150-400 with Belt Drive

The belt drive on these units is equipped with an adjustable pulley that permits adjustment of the blower speed. Follow these instructions to adjust the blower speed.

1. Turn off the gas and the electric power.
2. Loosen belt tension and remove the belt.
3. Loosen the setscrew on the side of the pulley away from the motor.
4. **To increase the blower speed, decreasing outlet temperature**, turn the adjustable half of the pulley inward. **To decrease the blower speed, increasing the outlet temperature**, turn the adjustable half of the pulley outward. One turn of the pulley will change the speed 8-10%.
5. Tighten the setscrew on the flat portion of the pulley shaft.
6. Replace the belt and adjust the belt tension. Adjust tension by turning the adjusting screw on the motor base until the belt can be depressed 1/2-3/4" (13-19mm). If the belt needs adjustment, the recommended method of adjusting the belt length is to count the number of links and remove one link for every 24. (A link is made up of two joining sections of belt. For easier removal of links, turn the belt inside out. But be sure to turn it back before installing.) Re-tighten the lock nut on the adjusting screw.
7. Turn on the gas and electric. Light the heater following the instructions on the lighting instruction plate.
8. Check the motor amps with an amp meter. The maximum motor amp rating on the motor nameplate must not be exceeded.

CAUTION: An external duct system static pressure not within the limits shown on the rating plate or improper adjustment of the motor pulley or belt may overload the motor.


6.0 Mechanical (cont'd)

6.4 Blowers, Belts, and Drives (cont'd)

**FIGURE 14 - Optional
Belt and Blower Guards
are either factory or
field installed**

6.4.3 Blower and Belt Guards

Guard options are designed to provide complete protection from the rotating drive and blower. Guards ordered as Option AZ6 or AZ7 are factory installed. Guards ordered as Option CD10 or CD12 are shipped separately for field installation. The blower guard only (Options AZ7 and CD12) is for Sizes 30-125 which have a direct drive motor. Both guards are used on Sizes 150-400 which have a belt drive. The belt guard includes a ground wire and screw. When the belt guard is field installed, be sure to attach the ground wire and insert the screw into one of the holes in the blower housing.



7.0 Electrical Supply and Wiring

7.1 General

All electrical wiring and connections, including electrical grounding **MUST** be made in accordance with the National Electric Code ANSI/NFPA No. 70 (latest edition) or, in Canada, with CSA Standard C22.1. In addition, the installer should be aware of any local ordinances or gas company requirements that might apply.

CAUTION: If any of the original wire as supplied with the appliance must be replaced, it must be replaced with wiring material having a temperature rating of at least 105°C, except for limit control, flame rollout, and sensor lead wires which must be 150°C. See Hazard Levels, page 2.

7.2 Supply Wiring

Check the rating plate on the heater for the supply voltage and current requirements. A dedicated line voltage supply with disconnect switch should be run directly from the main electrical panel to the heater. All external wiring must be within approved conduit and have a minimum temperature rise rating of 60°C. Conduit must be run so as not to interfere with the heater access panel.


If an optional stepdown transformer, Option CG2 or CG4, was ordered, follow the instructions shipped with the option package for attaching the transformer to the heater. For wiring connections, refer to the transformer and the wiring diagram on the heater.

If the unit is a Size 150-400 with a 460 or 575 supply voltage, a stepdown transformer is shipped separately and must be field installed on the unit. See the shipped-separate list of parts in Paragraph 3.2 and follow the instructions in **FIGURE 15**.

**FIGURE 15 - Sizes 150-
400 with 460 or 575
supply voltage require
installation of a 500VA
Stepdown Transformer**

Instructions for Installing the 500 VA Transformer supplied with Size 150-400 units ordered for 460V or 575V supply (Components listed in Paragraph 3.2)

1. The transformer is shipped in its own carton. Remove the transformer and the screws.
2. On the side of the heater opposite the access door, locate the factory-installed bracket. Position the transformer on the bracket and use the screws to attach the transformer.
3. Refer to the wiring diagram on the heater and the connection information on the transformer. The transformer has dual primary and secondary voltages, so be careful to make the connections correctly. Route the supply wiring in conduit from the transformer to the entrance at the rear of the heater. Conduit retainers may be attached to the edges of the heater cabinet or blower back.



CAUTION: Route wires so that they do not contact the flue wrapper or venter housing.


The electrical supply enters at the rear of the heater (See **FIGURE 17**).

Model UDBS includes a built-in disconnect switch. The switch on UDBS 30-125 has a 20A@115V and a 10A@230V inductive rating. The switch on UDBS 150-400 has a 30A@115V and a 15A@230V inductive rating. Model UDBS supply wiring connections are made inside the sealed electrical box. Sizes 30-125 connect to leads from the circuit board; Sizes 150-400 connect to terminals on either the starter or contactor. To maintain the sealing feature of the electrical box, always replace the cover plate.

Model UDBP supply wiring connections are made in the control compartment; Sizes 30-125 to leads from the circuit board and Sizes 150-400 directly to the terminals on the starter or contactor.

The circuit board (See **FIGURE 16**) is located inside on the bottom of the control compartment. The circuit board is polarity sensitive. It is advisable to check the electrical supply to be certain that the black wire is the “hot” wire and that the white wire is the neutral wire. The supply connection made to “L1” on the circuit board must be the “hot” wire.

FIGURE 16 - Supply Wiring Connections at the Circuit Board (DSI Integrated Control Module)




7.3 24V Control Wiring Connections

The terminal strip for 24 volt thermostat connections is located on the outside of the cabinet at the back of the heater (See **FIGURE 17**). Wires from the terminal strip are factory wired to the circuit board.

FIGURE 17 - Terminal Strip for 24-volt wiring is on the outside rear of the heater.


NOTE: The size of heater illustrated has a vertical terminal strip. Some sizes have a horizontal terminal strip.



7.0 Electrical Supply and Wiring (cont'd)

7.4 Wiring Diagrams

FIGURE 18A - Typical Wiring Diagram for Model UDBP or Model UDBS Sizes 30-125, Single Stage




- OPERATING SEQUENCE**
1. SET THERMOSTAT AT LOWEST SETTING, (FAN SWITCH AT "AUTO" POSITION).
 2. TURN ON MANUAL GAS VALVE.
 3. TURN ON POWER TO UNIT.
 4. SET THERMOSTAT AT DESIRED SETTING.
 5. LOW STAGE OF THERMOSTAT ENERGIZES THE BLOWER MOTOR FOR AIR RE-CIRCULATION.
 6. THERMOSTAT CALLS FOR HEAT, ENERGIZING THE VENTER MOTOR.
 7. VENTER PRESSURE SWITCH CLOSURES, FIRING UNIT AT FULL RATE.
 8. BURNER FLAME IS SENSED, AND IN 30 SECONDS THE BLOWER MOTOR IS ENERGIZED.
 9. IF THE FLAME IS EXTINGUISHED DURING MAIN BURNER OPERATION, THE INTEGRATED CONTROL SYSTEM CLOSURES THE MAIN VALVE AND MUST BE RESET BY INTERRUPTING POWER TO THE CONTROL CIRCUIT (SEE LIGHTING INSTRUCTIONS).
 10. SET FAN SWITCH AT "ON" POSITION FOR CONTINUOUS BLOWER OPERATION.

- NOTES**
1. THE FOLLOWING CONTROLS ARE FIELD INSTALLED OPTIONS: THERMOSTAT
 2. DOTTED WIRING INSTALLED BY OTHERS.
 3. CAUTION: IF ANY OF THE ORIGINAL WIRING AS SUPPLIED WITH THE APPLIANCE MUST BE REPLACED, IT MUST BE REPLACED WITH WIRING MATERIAL HAVING A TEMPERATURE RATING OF AT LEAST 105° C. EXCEPT FOR SENSOR LEAD WIRE AND LIMIT WIRING WHICH MUST BE 150° C.
 4. USE 18 GA. WIRE FOR ALL WIRING ON THE UNIT.
 5. LINE AND FAN MOTOR BRANCH WIRE SIZES SHOULD BE OF A SIZE TO PREVENT VOLTAGE DROPS BEYOND 5% OF SUPPLY LINE VOLTAGE.
 6. THREE SPEED MOTOR CONNECTIONS ARE AS FOLLOWS:
 MODELS 30 & 45 USE BLUE MOTOR LEAD, CAP BLACK AND RED.
 MODELS 60 - 125 USE BLACK MOTOR LEAD, CAP BLUE AND RED
 7. VERIFY JUMPER ON CL22 THERMOSTAT TERMINALS R TO RC.
 8. FAN SWITCH OR LOW STAGE OF CL22 THERMOSTAT ENERGIZES THE BLOWER MOTOR.
 9. HIGH STAGE OF CL22 THERMOSTAT INITIATES A CALL FOR HEAT.

| TOTAL WIRE LENGTH | DISTANCE FROM UNIT TO CONTROL | MIN. RECOMMENDED WIRE GAUGE |
|-------------------|-------------------------------|-----------------------------|
| 150' | 75' | #18 GA. WIRE |
| 250' | 125' | #16 GA. WIRE |
| 350' | 175' | #14 GA. WIRE |

UDBP & UDBS SERIES 30-125
 AG1-AK1-CL1 OR CL22
 WD# 185282 REV #3

FIGURE 18B - Typical Wiring Diagram for Model UDBP or Model UDBS, Sizes 30-125, Two Stage



OPERATING SEQUENCE


1. SET THERMOSTAT AT LOWEST SETTING, FAN SWITCH AT "AUTO" POSITION.
2. TURN ON MANUAL GAS VALVE.
3. TURN ON POWER TO UNIT.
4. SET THERMOSTAT AT DESIRED SETTING.
5. LOW STAGE OF THERMOSTAT CALLS FOR HEAT, ENERGIZING THE VENTER MOTOR.
6. VENTER PRESSURE SWITCH CLOSSES, FIRING UNIT AT LOW RATE.
7. BURNER FLAME IS SENSED, AND IN 30 SECONDS THE FAN MOTOR IS ENERGIZED.
8. HIGH STAGE OF THERMOSTAT CALLS FOR HEAT, FIRING UNIT AT FULL RATE.
9. SET FAN SWITCH AT "ON" POSITION FOR CONTINUOUS FAN OPERATION.
10. IF THE FLAME IS EXTINGUISHED DURING MAIN BURNER OPERATION, THE INTEGRATED CONTROL SYSTEM CLOSSES THE MAIN VALVE AND MUST BE RESET BY INTERRUPTING POWER TO THE CONTROL CIRCUIT (SEE LIGHTING INSTRUCTIONS).

NOTES

1. THE FOLLOWING CONTROLS ARE FIELD INSTALLED OPTIONS: THERMOSTAT
2. DOTTED WIRING INSTALLED BY OTHERS.
3. CAUTION: IF ANY OF THE ORIGINAL WIRING AS SUPPLIED WITH THE APPLIANCE MUST BE REPLACED, IT MUST BE REPLACED WITH WIRING MATERIAL HAVING A TEMPERATURE RATING OF AT LEAST 105° C. EXCEPT FOR SENSOR LEAD WIRE, FLAME ROLLOUT AND LIMIT WIRING WHICH MUST BE 150° C.
4. USE 18 GA. WIRE FOR ALL WIRING ON THE UNIT.
5. LINE AND FAN MOTOR BRANCH WIRE SIZES SHOULD BE OF A SIZE TO PREVENT VOLTAGE DROPS BEYOND 5% OF SUPPLY LINE VOLTAGE.
6. THREE SPEED MOTOR CONNECTIONS ARE AS FOLLOWS:
 MODELS 30 & 45 USE BLUE MOTOR LEAD, CAP BLACK AND RED.
 MODELS 60 - 125 USE BLACK MOTOR LEAD, CAP BLUE AND RED.
7. CAPACITOR IS REMOTE MOUNTED AND INCLUDED ONLY ON 115V MODELS 150-400 AND 208/230V MODELS 100-400.
8. VERIFY JUMPER ON THERMOSTAT TERMINALS R TO RC.

FIELD CONTROL WIRING

| TOTAL WIRE LENGTH | DISTANCE FROM UNIT TO CONTROL | MIN. RECOMMENDED WIRE GAUGE |
|-------------------|-------------------------------|-----------------------------|
| 150' | 75' | #18 GA. WIRE |
| 250' | 125' | #16 GA. WIRE |
| 350' | 175' | #14 GA. WIRE |




UDBP & UDBS SERIES 30-125
 AG2-CL22
 WD# 185263 REV. #2

7.0 Electrical Supply and Wiring (cont'd)

7.4 Wiring Diagrams (cont'd)


FIGURE 18C - Typical Wiring Diagram for Model UDBP or Model UDBS, Sizes 150-400, Single Stage



- OPERATING SEQUENCE**
1. SET THERMOSTAT AT LOWEST SETTING, (FAN SWITCH AT "AUTO" POSITION).
 2. TURN ON MANUAL GAS VALVE.
 3. TURN ON POWER TO UNIT.
 4. SET THERMOSTAT AT DESIRED SETTING.
 5. LOW STAGE OF THERMOSTAT ENERGIZES THE BLOWER MOTOR FOR AIR RE-CIRCULATION.
 6. THERMOSTAT CALLS FOR HEAT, ENERGIZING THE VENTER MOTOR.
 7. VENTER PRESSURE SWITCH CLOSURES, FIRING UNIT AT FULL RATE.
 8. BURNER FLAME IS SENSED, AND IN 30 SECONDS THE BLOWER MOTOR IS ENERGIZED.
 9. IF THE FLAME IS EXTINGUISHED DURING MAIN BURNER OPERATION, THE INTEGRATED CONTROL SYSTEM CLOSURES THE MAIN VALVE AND MUST BE RESET BY INTERRUPTING POWER TO THE CONTROL CIRCUIT (SEE LIGHTING INSTRUCTIONS).
 10. SET FAN SWITCH AT "ON" POSITION FOR CONTINUOUS BLOWER OPERATION.
- NOTES**
1. THE FOLLOWING CONTROLS ARE FIELD INSTALLED OPTIONS: THERMOSTAT
 2. DOTTED WIRING INSTALLED BY OTHERS.
 3. CAUTION: IF ANY OF THE ORIGINAL WIRING AS SUPPLIED WITH THE APPLIANCE MUST BE REPLACED, IT MUST BE REPLACED WITH WIRING MATERIAL HAVING A TEMPERATURE RATING OF AT LEAST 105° C, EXCEPT FOR SENSOR LEAD WIRE AND LIMIT WIRING WHICH MUST BE 150° C.
 4. USE 18 GA. WIRE FOR ALL WIRING ON THE UNIT.
 5. LINE AND FAN MOTOR BRANCH WIRE SIZES SHOULD BE OF A SIZE TO PREVENT VOLTAGE DROPS BEYOND 5% OF SUPPLY LINE VOLTAGE.
 6. CAPACITOR IS REMOTE MOUNTED.
 7. VERIFY JUMPER ON CL22 THERMOSTAT TERMINALS R TO RC.
 8. FAN SWITCH OR LOW STAGE OF CL22 THERMOSTAT ENERGIZES THE BLOWER MOTOR.
 9. HIGH STAGE OF CL22 THERMOSTAT INITIATES A CALL FOR HEAT.
 10. WHEN PROVIDING OR REPLACING FUSES IN THE FUSIBLE DISCONNECT SWITCH USE DUAL ELEMENTS TIME DELAY FUSES AND SIZE ACCORDING TO 1.25 TIMES THE MAXIMUM TOTAL INPUT AMPS.
 11. DISCONNECT SWITCH IS FIELD FURNISHED OR AVAILABLE FROM FACTORY AS AN OPTION.

UDBP & UDBS SERIES 150-400
AG1-AN2-CL1 OR CL22
WD# 186204 REV #5

FIGURE 18D - Typical Wiring Diagram for Model UDBP or Model UDBS, Sizes 150-400, Two Stage





OPERATING SEQUENCE

1. SET THERMOSTAT AT LOWEST SETTING, FAN SWITCH AT "AUTO" POSITION.
2. TURN ON MANUAL GAS VALVE.
3. TURN ON POWER TO UNIT.
4. SET THERMOSTAT AT DESIRED SETTING.
5. LOW STAGE OF THERMOSTAT CALLS FOR HEAT, ENERGIZING THE VENTER MOTOR.
6. VENTER PRESSURE SWITCH CLOSSES, FIRING UNIT AT LOW RATE.
7. BURNER FLAME IS SENSED, AND IN 30 SECONDS THE FAN MOTOR IS ENERGIZED.
8. HIGH STAGE OF THERMOSTAT CALLS FOR HEAT, FIRING UNIT AT FULL RATE.
9. SET FAN SWITCH AT "ON" POSITION FOR CONTINUOUS FAN OPERATION.
0. IF THE FLAME IS EXTINGUISHED DURING MAIN BURNER OPERATION, THE INTEGRATED CONTROL SYSTEM CLOSSES THE MAIN VALVE AND MUST RESULT IN INTERRUPTING POWER TO THE CONTROL CIRCUIT (SEE LIGHTING INSTRUCTIONS).

NOTES

1. THE FOLLOWING CONTROLS ARE FIELD INSTALLED OPTIONS: THERMOSTAT
2. DOTTED WIRING INSTALLED BY OTHERS.
3. CAUTION: IF ANY OF THE ORIGINAL WIRING AS SUPPLIED WITH THE APPLIANCE MUST BE REPLACED, IT MUST BE REPLACED WITH WIRING HAVING A TEMPERATURE RATING OF AT LEAST 90°C. EXCEPT FOR SENSOR LEAD WIRE, FLAME ROLLOUT AND LIMIT WIRING WHICH MUST BE 150° C.
4. USE 18 GA. WIRE FOR ALL WIRING ON THE UNIT.
5. USE 1/2" FLEXIBLE CABLE FOR ALL CABLES. CABLES SHOULD BE OF A SIZE TO PREVENT VOLTAGE DROPS BEYOND 5% OF SUPPLY LINE VOLTAGE.
6. CAPACITOR IS REMOTE MOUNTED AND INCLUDED ONLY ON 115V MODELS 150-400 AND 208/230V MODELS 100-400.
7. CAPACITOR IS REMOTE MOUNTED AND INCLUDED ONLY ON MODELS 150 - 400.
8. VERIFY JUMPER ON THERMOSTAT TERMINALS R TO RG.

 FACTORY WIRING
 FIELD WIRING
 OPTIONAL FACTORY WIRING
 OPTIONAL FIELD WIRING

| FIELD CONTROL WIRING | | |
|----------------------|-------------------------------|-----------------------------|
| TOTAL WIRE LENGTH | DISTANCE FROM UNIT TO CONTROL | MIN. RECOMMENDED WIRE GAUGE |
| 150' | 75' | #18 GA. WIRE |
| 250' | 125' | #16 GA. WIRE |
| 350' | 175' | #14 GA. WIRE |

UDBP & UDBS SERIES 150-400
AG2-AN2-CL22
WD# 186441 REV #3

7.0 Electrical Supply and Wiring (cont'd)

7.5 Electrical Operating Components

7.5.1 Combustion Air Proving (Pressure) Switch

The combustion air proving switch is a pressure sensitive switch that monitors air pressure to ensure that proper combustion airflow is available. On Model UDBP, the switch is a single pole/normally open device which closes when a negative pressure is sensed in the venter housing. On Model UDBS, the switch senses the differential pressure between the negative pressure in the venter housing and the pressure in the cabinet. (For switch location, see **FIGURE 22**, page 35.)

On startup when the heater is cold, the sensing pressure is at the most negative level, and as the heater and flue system warm up, the sensing pressure becomes less negative. After the system has reached equilibrium (about 20 minutes), the sensing pressure levels off.

If a restriction or excessive flue length or turns cause the sensing pressure to be outside the switch setpoint, the pressure switch will function to shutoff the main burner. The main burner will remain off until the system has cooled and/or the flue system resistance is reduced.

The Tables on the left below list the approximate water column negative pressure readings and switch setpoints for sea level operating conditions for Model UDBP heaters. The Table on the right lists the approximate water column differential pressure readings and switch setpoints for sea level operating conditions for Model UDBS heaters.

DANGER

Safe operation of this unit requires proper venting flow. NEVER bypass combustion air proving switch or attempt to operate the unit without the venter running and the proper flow in the vent system. Hazardous conditions could result. See Hazard Intensity Levels, page 2.

Pressure Switch Settings

| Model UDBP | Startup Cold | Equilibrium Hot | Setpoint OFF | Setpoint ON | Label Color | Switch P/N | Model UDBS | Startup Cold | Equilibrium Hot | Setpoint OFF | Setpoint ON | Label Color | Switch P/N |
|------------|---------------------------------|-----------------|--------------|-------------|-------------|------------|------------|-------------------------------------|-----------------|--------------|-------------|-------------|------------|
| | Negative Pressure (inches w.c.) | | | | | | | Differential Pressure (inches w.c.) | | | | | |
| 30 | 1.0 | 0.8 | 0.40 | 0.6 | Green | 197030 | 30 | 1.0 | 0.8 | 0.40 | 0.6 | Green | 197030 |
| 45 | 1.0 | 0.8 | 0.40 | 0.6 | Green | 197030 | 45 | 1.0 | 0.8 | 0.50 | 0.7 | Orange | 196388 |
| 60 | 1.0 | 0.8 | 0.50 | 0.7 | Orange | 196388 | 60 | 1.0 | 0.8 | 0.60 | 0.8 | Lt Blue | 197029 |
| 75 | 1.0 | 0.8 | 0.50 | 0.7 | Orange | 196388 | 75 | 1.0 | 0.7 | 0.50 | 0.7 | Orange | 196388 |
| 100 | 0.8 | 0.7 | 0.40 | 0.6 | Green | 197030 | 100 | 0.8 | 0.6 | 0.40 | 0.6 | Green | 197030 |
| 125 | 0.6 | 0.6 | 0.40 | 0.6 | Green | 197030 | 125 | 0.6 | 0.6 | 0.45 | 0.6 | Pink | 197032 |
| 150, 175 | 0.8 | 0.7 | 0.40 | 0.6 | Green | 197030 | 150, 175 | 0.8 | 0.6 | 0.40 | 0.6 | Green | 197030 |
| 200, 225 | 2.2 | 1.5 | 1.10 | 1.3 | Blue | 201158 | 200, 225 | 2.2 | 1.5 | 1.10 | 1.3 | Blue | 201158 |
| 250, 300 | 2.3 | 1.6 | 1.10 | 1.3 | Blue | 201158 | 250, 300 | 2.3 | 1.6 | 1.10 | 1.3 | Blue | 201158 |
| 350 | 2.6 | 1.8 | 1.10 | 1.6 | Blue | 201158 | 350 | 2.6 | 1.8 | 1.10 | 1.6 | Blue | 201158 |
| 400 | 1.7 | 1.4 | 1.10 | 1.3 | Blue | 201158 | 400 | 1.7 | 1.4 | 1.10 | 1.3 | Blue | 201158 |

7.5.2 Limit Control

All units are equipped with a temperature activated auto reset limit control. The control is factory set and is non-adjustable. If the setpoint is reached, the limit control will interrupt the electric supply to the gas valve. This safety device provides protection in the case of motor failure or lack of airflow due to a restriction at the inlet or outlet. (For location, see **FIGURE 22**, page 35.)

CAUTION: The auto reset limit control will continue to shut down the heater until the cause is corrected. Never bypass the limit control; hazardous conditions could result. See Hazard Intensity Levels, page 2.

7.5.3 Door Switch - Model UDBS only

All sizes of Model UDBS heaters are equipped with a door switch which prevents the heater from operating when the service door panel is open. The service panel of a Model UDBS is equipped with a pliable gasket material that fully seals the door to provide added protection from building air entering the combustion zone of the heater. (For switch location, see **FIGURE 22**, page 35.)

7.5.4 Gas Valve

The main operating gas valve is powered by the 24-volt control circuit through the thermostat and safety controls. The main control valve is of the diaphragm type providing regulated gas flow preset at the factory. (For location, see **FIGURE 22**, page 35.)

WARNING

The operating valve is the prime safety shutoff. All gas supply lines must be free of dirt or scale before connecting the unit to ensure positive closure. See Hazard Levels, page 2.

7.5.5 Blower Motor

Blower Model **Sizes 30-125** are equipped with a direct drive motor. Blower Model **Sizes 150-400** have an adjustable belt drive motor from 1/4 to 5 HP.

Most blower motors are equipped with thermal overload protection of the automatic reset type. If a motor is not equipped with thermal overload protection, the unit will be equipped with a motor with an adjustable thermal overload starter. The adjustable setting on the starter will be factory set to match the full load amp draw of the motor and sealed. No change should be made to starter set unless the original motor is replaced. Starters are manual reset. If an overload condition is experienced, the condition must be corrected, and the starter must be manually reset.

After the installation is complete including all ductwork, the amp draw of the motor should be checked with an amp meter to verify that the motor amp rating on the motor nameplate is not being exceeded. Amps may be adjusted downward by reducing blower speed or by increasing the duct system static pressure. The temperature rise must be within the range specified on the unit rating plate

7.5.6 Venter Motor

The venter motor is assembled to the venter wheel and operates to provide combustion airflow. Operation is controlled by the ignition control module (circuit board); refer to ignition system in Paragraph 8.3.

8.0 Controls and Operation

8.1 Thermostat

Use either an optional thermostat available with the heater or a field-supplied 24-volt thermostat. Install according to the thermostat manufacturer's instructions, paying particular attention to the requirements regarding the location of the thermostat.

Make sure that, if the thermostat has a heat anticipator setting, it is set to 0.6 amps (or in accordance with the amperage value noted on the wiring diagram of your heater).

Connect the thermostat at the terminal strip on the back of the heater. The strip has four terminals, R, G, W1, and W2; refer to the wiring diagram.

IMPORTANT: This unit **MUST** be operated by a 24-volt thermostat. Never use a line voltage disconnect switch as a means of operating the heater.

Unit Mounted Thermostat, Option CM3 - If the heater was ordered with Option CM3, a kit for mounting the thermostat on the rear of the heater is shipped separately. Follow the instructions in the option package to attach the bracket.

Select a snap-action thermostat when using the unit mounted thermostat bracket. Do not use a mercury switch thermostat because the vibration may cause excessive unit cycling. Be careful with the thermostat leads; shorting the thermostat wires to a metal surface will cause the transformer to fail.

Multiple Heater Control, Option CL31 and Option CL32 - If the heater was ordered with a multiple heater control option, one thermostat can be used to control up to six heaters. The option includes a 40VA transformer that replaces the standard transformer in the "controlling" unit and a relay assembly that attaches to the additional unit. Option CL31 provides for control of two heaters. If control of more heaters is desired (up to six total), Option CL32 which is the relay assembly only must be added to each additional heater.


The option packages are shipped separately and include complete instructions on installation and wiring.

8.0 Controls and Operation (cont'd)

8.2 DDC Controls, Options D10 and D14

If the heater was ordered with Option D10 or D14, it is equipped with a Novar Minio control module. The Novar control with its accompanying relays and power transformer are mounted in the control compartment of the unit. See **FIGURE 19A**. This control offers a wide variety of input and output points that can be configured to meet a wide range of building management applications. User-selectable input types are Thermistor, 4-20 milliamp, 1-5 volts, or digital.

FIGURE 19A -
DDC Control with
Transformer and
Relays is Mounted on
a Specially Designed
Bracket in the Control
Compartment



Control **Option D10** includes the controller and the sensor to be field mounted at the heater discharge. **Option D14** requires a field-supplied sensor that is compatible with the control. For regulatory compliance specifications, and safety precautions, review the control manufacturer's installation instructions in the literature bag.


The recommended location for mounting the sensor is on the side of a field-installed optional downturn nozzle. See **FIGURE 19B** for an illustration of the sensor included with Option D10 and dimensions for mounting it on the nozzle side.

FIGURE 19B - Recommended Location
for Mounting the Sensor is on the Side
Panel of a Discharge Nozzle (Option CD
2, 3, or 4)



Sensor

Before installing the
discharge nozzle, drill the
holes in the side panel as
illustrated.




Mount the sensor on the nozzle side.

Drill a 7/8" hole in the cabinet top above the controller and install the bushing supplied with the unit for running the sensor wire. Sensor wire is field-supplied. Wire the sensor to the controller as illustrated on the heater wiring diagram.

8.3 Ignition System

This heater is equipped with a direct spark integrated control module (circuit board). The module monitors the safety devices and controls the operation of the blower and venter motors and the gas valve between heat cycles.

FIGURE 20 – DSI Integrated Control Module (circuit board)



Normal Heat Cycle Operating Sequence

LED lights are visible through viewport on Model UDBS. Remove door panel to view LED lights on Model UDBP.

1) Call for Heat - The thermostat calls for heat by energizing the “W” terminal. The control checks to see that the limit switch is closed and the pressure switch is open. If the limit switch is open, the control responds as defined in the “Abnormal Heat Cycle, Limit Switch Operation”. If the pressure switch is closed, the control will do four flashes on the green LED and wait indefinitely for the pressure switch to open. If the pressure switch is open, the control proceeds to prepurge.

2) Prepurge - The control energizes the venter motor and waits for the pressure switch to close. If the pressure switch does not close within 30 seconds of the venter motor energizing, the control will do two flashes on the green LED. The control will leave the venter motor energized indefinitely as long as the call for heat remains and the pressure switch is open.

When the pressure switch is proven closed, the control begins the prepurge time. If flame is present any time while in prepurge, the prepurge time is restarted. If flame is present long enough to cause lockout, the control responds as defined in “Fault Modes, Undesired Flame”.

The control runs the venter motor for a 20 second prepurge time, then proceeds to the ignition trial period.

3) Ignition Trial Period - The control energizes the spark and main gas valve. The venter remains energized. If flame is sensed during the first 16 seconds, the spark is de-energized and the control proceeds to heat fan/blower on delay. If flame has not been sensed during the first 16 seconds, the control de-energizes the spark output and keeps the gas valve energized for an additional one second flame proving period. If flame is not present after the flame proving period, the control de-energizes the gas valve and proceeds with ignition re-tries as specified in “Abnormal Heat Cycle, Ignition Retry”. If flame is present, the control proceeds to the fan/blower on delay.

4) Fan/Blower On Delay - The control waits for 30 seconds from the time the gas valve opened and then energizes the fan/blower motor. The gas valve and venter motor remain energized. The control proceeds to steady heat mode.

8.0 Controls and Operation (cont'd)

8.3 Ignition System (cont'd)

Abnormal Heat Cycle Functions

Normal Heat Cycle Operating Sequence (cont'd)

5) Steady Heat - Control inputs are continuously monitored to ensure limit and pressure switches are closed, flame is established, and the thermostat call for heat remains. When the thermostat call for heat is removed, the control de-energizes the gas valve and begins post-purge and fan/blower off delay timing.

6) Post Purge - The venter motor output remains on for a 45-second post-purge period after the thermostat is satisfied.

7) Fan/Blower Off Delay - The fan/blower motor is de-energized after a blower off delay of 120 seconds:

Interrupted Thermostat Call for Heat - If the thermostat demand for heat is removed before the flame is recognized, the control will run the venter motor for the post purge period and de-energize all outputs.

If the thermostat demand for heat is removed after successful ignition, the control will de-energize the gas valve, run the venter motor through post purge, and run the fan/blower motor on heat speed for the selected delay off time.

Ignition Retry - If flame is not established on the first trial for ignition period, the control de-energizes the gas valve and the venter motor remains energized for an inter-purge period of 10 seconds. The spark and gas valve are then re-energized, and the control initiates another trial for ignition.

If flame is not established on the second trial for ignition, the control de-energizes the gas valve, energizes the fan/blower motor on heat speed, and venter motor remains energized. The fan/blower motor is shut off after 120 seconds. When the fan/blower motor de-energizes, the spark and gas valve are re-energized and the control initiates another trial for ignition. (This blower delay is self-healing feature for an open auxiliary limit switch).

If flame is not established on the third trial for ignition period, the control de-energizes the gas valve, and the venter motor remains energized for an inter-purge period of 10 seconds. The control then re-energizes the gas valve and spark and initiates another trial for ignition.

If flame is not established on the fourth trial for ignition (initial try plus 3 re-tries), the control de-energizes the gas valve and goes into lockout. The control goes to one flash on the green LED to indicate ignition failure lockout.

Limit Switch Operation - The limit switch is ignored unless a call for heat is present (W energized). If the limit switch is open and a call for heat is present, the control de-energizes the gas valve and turns the fan/blower motor on heat speed and runs the venter motor. The control will be in soft lockout and flashing fault code "3" before returning to normal operation.

When the switch re-closes or the call for heat is lost, the control runs the venter motor through post purge and runs the blower/fan motor through the selected fan off delay.

Pressure Switch - If the pressure switch opens before the trial for ignition period, the venter motor will run through the pressure switch recognition delay (2 seconds), the gas valve will be de-energized, and the venter motor will run through the postpurge time. The control will re-start the heat cycle at the pressure switch proving state if the call for heat still exists.

Pressure switch opening for less than 2 seconds during the trial for ignition period shall not interrupt the heat cycle. (Gas valve will de-energize while the pressure switch is open.)

If the pressure switch opens after a successful ignition, the control will de-energize the gas valve. If flame is lost before the end of the 2 second pressure switch recognition delay, the control will respond to the loss of flame. If the pressure switch remains open for 2 seconds and the flame remains, the control de-energizes the gas valve, the venter motor runs through post-purge, and the fan/blower motor runs on heat speed through the selected blower off delay. When the blower off delay is over, the fan/blower motor is de-energized, and a heat cycle is begun if the call for heat still exists.

Continuous Blower Operation

When the thermostat calls for continuous blower (G) without a call for heat, the blower motor is energized after a .25 second delay. **NOTE:** This brief on delay is to allow the “G” terminal to energize slightly before “Y” and an external changeover relay to switch from “G” to “W” without causing momentary glitches in the fan/blower output. The blower remains energized as long as the call for fan remains without a call for heat. If a call for heat (W) occurs during continuous blower, the fan/blower will de-energize. A call for blower is ignored while in lockout.

Fault Modes

Undesired Flame - If flame is sensed longer than 20 seconds while the gas valve is de-energized, the control shall energize the venter motor and fan/blower motor on heat speed. When flame is no longer sensed, the venter motor will run through postpurge, and the fan/blower motor will run through the selected heat blower off delay time. The control will do a soft lockout, but will still respond to open limit and flame. The FLAME (yellow) LED shall flash rapidly when lockout is due to undesired flame.

Gas Valve Relay Fault - If the control senses the gas valve as energized for more than one second when the control is not attempting to energize the gas valve, or the gas valve is sensed as not energized when it is supposed to be energized, then the control will lockout with green LED off. The control assumes either the contacts of the relay driving the gas valve have welded shut, or the sensing circuit has failed. The venter motor is forced off to open the pressure switch to stop gas flow unless flame is present.

If the gas valve was sensed as closed when it should be open, and has not de-energized after the venter motor was shutoff for 15 seconds, then the venter motor is re-energized to vent the unburned gas.

Lockout

Soft Lockout - The control shall not initiate a call for heat or call for continuous blower while in lockout. The control will still respond to an open limit and undesired flame. Lockout shall automatically reset after one hour. Lockout may be manually reset by removing power from the control for more than one second or removing the thermostat call for heat for more than one and less than 20 seconds.

Hard Lockout - If the control detects a fault on the control board, the status LED will be de-energized, and the control will lockout as long as the fault remains. A hard lockout will automatically reset if the hardware fault clears.

Power Interruption - During a momentary power interruption or at voltage levels below the minimum operating voltage (line voltage or low voltage) the system will self-recover without lockout when voltage returns to the operating range.

Power interruptions of less than 80mS shall not cause the control to change operating states. Power interruptions greater than 80mS may cause the control to interrupt the current operating cycle and re-start.

9.0 Commissioning and Startup

9.1 Check the installation prior to startup:

- ☐ Check to be sure that all screws used to hold shipping brackets were re-installed in the heater cabinet.
- ☐ Check suspension. Unit must be secure and level.
- ☐ Check clearances from combustibles. Requirements are in Paragraph 4.1.
- ☐ Check vent system to be sure that it is installed according to the instructions in the appropriate Vent Installation Manual as listed in Paragraph 1.2.2.
- ☐ Check piping for leaks and proper gas line pressure. Bleed gas lines of trapped air. See Paragraph 6.1.
- ☐ **IMPORTANT** - Before applying power to a unit with a belt drive, check blower and motor pulleys to be sure they are secure to the shaft. Check blower and pulleys for free movement. Check belt tension and alignment. See Paragraph 6.4.
- ☐ Check electrical wiring. Be sure all wire gauges are as recommended. A service disconnect switch should be used. Verify that fusing or circuit breakers are adequate for the load use.
- ☐ Check polarity. Verify that line voltage exists between the black "L1" and earth ground.
- ☐ If installed in California, verify that California Warning Label is displayed.

9.2 Heater Startup:

WARNINGS

For your safety, read before operating. If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury, or loss of life.

- This appliance does not have a pilot. It is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand.
- Before operating, smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

WHAT TO DO IF YOU SMELL GAS


- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Leave the building immediately.
- Immediately call your gas supplier from a phone remote from the building. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call your fire department.

- Use only your hand to turn the gas control ON/OFF knob on the gas valve. Never use tools. If the valve ON/OFF knob will not turn by hand, do not try to repair it. Call a qualified service technician. Force or attempted repair may result in a fire or explosion.
- Should overheating occur, or the gas supply control system fail to shut off the flow of gas, turn off the manual gas valve to the appliance before shutting off the electrical supply.
- Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.

Sequence of Operation

1. Set the thermostat at lowest setting.
2. Turn off all electric power to the appliance.
3. This appliance is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand. Open the access door and locate the gas control (ON/OFF) knob or switch on the gas valve. (See **FIGURE 17.**)

FIGURE 17 - Gas Valve



9.3 Check installation after startup:

4. On the top of the valve, turn the gas control switch to “OFF” or the knob clockwise to “OFF”.
 5. Wait five (5) minutes to clear out any gas. Then smell for gas, including near the floor. **If you smell gas, STOP!** and follow the steps in the **WARNINGS** printed above or on the Operating Label on the heater. If you do not smell gas, proceed to the next step.
 6. Turn the gas control switch to “ON” or the knob counterclockwise to “ON”.
 7. Close the access door.
 8. Turn on the electric power to the heater.
 9. Set the thermostat to the desired setting.
- NOTE:** If the appliance does not operate, follow the instructions “To Turn Off Gas to Appliance” printed below (and on the Operating Label on the heater) and call your service technician.
10. Thermostat calls for heat, energizing the venter motor.
 11. Venter pressure switch closes, firing the unit.
 12. Burner flame is sensed and in 30 seconds after the gas valve is energized, the blower motor is energized.
 13. If the flame is extinguished during the main burner operation, the integrated control system closes the main valve and must be reset by interrupting power to the control circuit. (See lighting instructions on the heater.).

TO TURN OFF GAS TO THE APPLIANCE

- 1) Set thermostat to lowest setting
- 2) If service is to be performed, turn off all electric power to the appliance.
- 3) Open the access door.
- 4) Turn the gas control switch to “OFF” or knob clockwise to “OFF” (Do not force).
- 5) Close the access door.

☐ Vent System Testing Procedure

The steps below shall be followed with each heater or utility heater connected to the venting system placed in operation while any other appliance(s) connected to the venting system(s) is not in operation.

1. Seal unused openings(s) in the venting system.
 2. Inspect the venting system for proper size and horizontal pitch as required in the National Flue Gas Code, ANSI Z223.1/NFPA 54, or the Natural Gas and Propane Installation Code, CSA B149.1, and the venting manual instructions. Verify that there is no blockage or restriction, leakage, corrosion, and/or other deficiencies that could cause an unsafe condition.
 3. In so far as is practical, close all doors, windows, other open spaces within the building, and all doors between the space in which the appliance(s) connected to the venting system is located. Turn on clothes dryers and any exhaust fans (such as range hoods and bathroom exhausts) so they operate at maximum speed. Do not operate a summer exhaust fan. Close fireplace dampers.
 4. Following the lighting instructions, place the utility heater being inspected in operation. Adjust the thermostat so that the utility heater will operate continuously.
 5. After it has been determined that each utility heater connected to the venting system properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers, and any other gas-burning appliance to their previous condition of use.
 6. If improper venting is observed during any of the above tests, the venting system must be corrected.
- ☐ With the unit in operation, measure valve outlet gas pressure. If operated at high altitude, adjust outlet gas pressure for altitude.
See information and instructions in Paragraph 6.1.
- ☐ Turn the unit off and on, pausing two minutes between each cycle. Observe for smooth ignition.

9.0 Commissioning and Startup (cont'd)

9.3 Check installation after startup (cont'd)

- ☐ Place the "Literature Bag" containing the Limited Warranty, this booklet, the venting manual, and any control or optional information in an accessible location near the heater.
- ☐ **IMPORTANT:** After at least 8 hours but not longer than a week of operation, recheck the blower wheel, all set screws, blower pulley, motor pulley, and belt tension. Make any required adjustments.

DANGER

The gas burner in this gas-fired equipment is designed and equipped to provide safe controlled complete combustion. However, if the installation does not permit the burner to receive the proper supply of combustion air, complete combustion may not occur. The result is incomplete combustion which produces carbon monoxide, a poisonous gas that can cause death. Safe operation of indirect-fired gas burning equipment requires a properly operating vent system that vents all flue products to the outside atmosphere. **FAILURE TO PROVIDE PROPER VENTING WILL RESULT IN A HEALTH HAZARD WHICH COULD CAUSE SERIOUS PERSONAL INJURY OR DEATH.**

Always comply with the combustion air requirements in the installation codes and in Paragraph 6.2. Combustion air at the burner should be regulated only by manufacturer-provided equipment. **NEVER RESTRICT OR OTHERWISE ALTER THE SUPPLY OF COMBUSTION AIR TO ANY HEATER.** Model UDBP units installed in a confined space must be supplied with air for combustion as required by Code and in Paragraph 6.2 of this heater installation manual. **MAINTAIN THE VENT OR VENT/COMBUSTION AIR SYSTEM IN STRUCTURALLY SOUND AND PROPER OPERATING CONDITION.**

10.0 Maintenance and Service

WARNING

If you turn off the power supply, turn off the gas. See Hazard Levels, page 2.

The material contained in the MAINTENANCE AND SERVICE Section of this manual is designed to aid a qualified service person in maintaining and servicing this equipment. This heater will operate with a minimum of maintenance. To ensure long life and satisfactory performance, a heater that is operated under normal conditions should be inspected and cleaned at the start of each heating season. If the heater is operating in an area where an unusual amount of dust or soot or other impurities are present in the air, more frequent maintenance is recommended.

When any service is completed, be careful to reassemble correctly to ensure that no unsafe conditions are created. When re-lighting, always follow the lighting instructions on the heater.

10.1 Maintenance Schedule


Maintenance Schedule - The following procedures should be carried out at least annually (See **FIGURE 22** and Paragraphs 10.2.1 - 10.2.13.):

NOTE: If replacement parts are required, use only factory-authorized parts.

- **Clean all dirt, lint, and grease from the combustion air opening (UDBP) and venter assembly.**
- **Clean all dirt, lint, and grease from the blower, motor, and if equipped, the optional blower guard.**
- **Check the belt for tension and wear. Replace a belt that may fail before the next scheduled maintenance.**
- **Check the heat exchanger both internally and externally.**
- **Check the burner for scale, dust, or lint accumulation. Clean if needed.**

- Check gas valve to ensure that gas flow is being shutoff completely.
- Check the vent or vent/combustion air system for soundness. Clean openings. Replace any parts that do not appear sound.
- Check the wiring for any damaged wire. Replace damaged wiring. (See Paragraph 7 for replacement wiring requirements.)

FIGURE 22 - Location of Controls



10.2 Maintenance Procedures

10.2.1 Heat Exchanger Maintenance

This heater has a T²CORE[®] heat exchanger.

Remove any external dirt or dust accumulation. Visually check the heat exchanger for cracks and holes. If a crack or hole is observed, replace the heat exchanger.

NOTE: Inspection of the lower portion of the heat exchanger is done with the burner removed. See the Burner Service section below for information on inspecting the lower portion of the heat exchanger.

10.0 Maintenance and Service (cont'd)

10.2 Maintenance Procedures (cont'd)

CAUTION: Use of eye protection is recommended.

10.2.2 Burner Maintenance


This heater is equipped with a T^{CORE}²® burner.

Inspect the burner/control compartment annually to determine if cleaning is necessary. If there is an accumulation of dirt, dust, and/or lint, clean the compartment and follow the instructions below to remove and clean the burner.

Burner Removal Instructions (Refer to FIGURE 23.)

1. Outside the cabinet, shut the gas supply off at the manual valve ahead of the union.
2. Turn off electric supply.
3. Disconnect the gas supply at the union outside of the cabinet.
4. Remove the access panel.
5. **Disconnect and Move the Gas Train** - At the gas valve, mark and disconnect the wires. Carefully remove the burner orifice and orifice adapter locking nut. Slide the orifice adapter out through the bracket on the burner pushing the gas train to the right. This will move the gas train out of the way.
6. **Move the Control Assembly** - Remove the two screws holding the control assembly bracket. Being careful not to disconnect any wires, slide the control assembly to the right.
7. **Remove Secondary Air Baffles (Sizes 60-400 only)** - Vertical along the right side of the burner, locate the flat plate(s) identified as the secondary air baffle(s). The quantity of baffles could be one to four depending on heater size. Each baffle is held in place by one screw. **For re-assembly, on the secondary air shield, mark the location (top and bottom) of each baffle.** Remove all baffles.
8. **Remove Burner Assembly**
 - a) Locate the burner body supports. Depending on the size, the burner will have two or more supports. At each support, remove the one screw that attaches it to the secondary air shield.
 - b) Holding the venturi tube, slide the entire burner assembly slightly to the right to disengage the burner from the supports on the left. Then rotate the open end of the venturi tube inward toward the heater. Carefully pull the burner assembly out of the cabinet.

FIGURE 23 - Burner Removal (UDBP illustrated; same process for both UDBP and UDBS)



Inspect and Clean the Burner

With the burner assembly removed, shine a flashlight on the burner ribbons. Look for carbon buildup, scale, dust, lint, and/or anything that might restrict flow through the spaces between the burner ribbons. Holding the burner assembly so that any foreign material will fall away from the burner, use a stiff bristle brush to loosen and remove any foreign material(s). If the burner is excessively dirty, remove one of the burner end caps. Remove the four screws that hold the end cap to the burner housing. Lightly tap the end cap to remove it.

Inspect the Lower Portion of the Heat Exchanger (with burner assembly removed)

Re-Install the Burner

Clean all foreign material from the burner and venturi. After the burner is thoroughly clean, replace the end cap making certain that it is tight against the burner housing. **NOTE:** If any of the burner components are damaged or deteriorated, replace the burner assembly.

At the burner flame entrance of each tube, shine a bright light into each heat exchanger section. With the light shining into the heat exchanger, observe the outside for visible light. Repeat this procedure with each heat exchanger section. If any light is observed, replace the heat exchanger.

Instructions to Re-Install the Burner (Refer to FIGURE 23)

1. **Attach the Burner Assembly** - Holding the venturi tube, slide the entire burner assembly into position. Align the supports on the left side with the slots in the burner shield; sliding the supports into the slots. On the right, re-attach each burner body support to the secondary air shield.
2. **Attach the Secondary Air Baffles (Sizes 60-400 only)** - Re-attach the secondary air baffles as marked. Baffles may be different sizes and each **must** be attached in the correct location.
3. **Attach the Control Assembly** - Carefully slide the control assembly into position. Re-attach with the same screws. Check to be sure all wire connections are secure.
4. **Attach the Gas Train** - Slide the gas train so that the orifice adapter is through the bracket. Fasten the gas train to the bracket with the locking nut. Install the gas orifice. Re-connect the wires to the gas valve.
5. Close the access panel.
6. Reconnect the gas supply at the union outside of the cabinet. Leak test the connection with leak detecting solution.
7. Turn on the electric and the gas. Check for proper operation.

10.2.3 Burner Orifice

Burner orifice usually only needs to be replaced when installing a gas conversion kit. If ordering a replacement orifice only, give BTUH content and specific gravity of gas, as well as the model and serial number of the unit. When removing or replacing the burner orifice, be careful not to damage the venturi tube and/or the bracket.

10.2.4 Ignition System


DSI Integrated Control Module (circuit board) - See **FIGURE 24**. The module monitors the operation of the heater including ignition. The only replaceable component is the 3 amp Type ATC or ATO fuse. If the fuse is blown, the problem is most likely an external overload. Correct the problem and replace the fuse.

Do not attempt to disassemble the control module. However, each heating season check the lead wires for insulation deterioration and good connections.

Proper operation of the direct spark ignition system requires a minimum flame signal of 1.0 microamps as measured by a microammeter.

FIGURE 24 - DSI Integrated Control Module (Circuit Board)

CAUTION: Due to high voltage on the spark wire and electrode, do not touch when energized. See Hazard Levels, page 2.



For further information and check out procedure on the direct spark ignition system, refer to Paragraph 8.3 and the Troubleshooting Flow Chart in Paragraph 10.3.



Ignitor - Refer to **FIGURE 22** and locate the ignitor. Disconnect the wire; remove the screw and the ignitor. Clean the ignitor assembly with an emery cloth.


Spark gap must be maintained to 1/8". See **FIGURE 25**.

10.0 Maintenance and Service (cont'd)

10.2 Maintenance Procedures (cont'd)

10.2.5 Venter Motor and Wheel

FIGURE 26 - Venter Wheel Position on Shaft




10.2.6 Blower, Motor, and Guards

10.2.7 Operating Gas Valve

10.2.4 Ignition System (cont'd)

FIGURE 25 - Ignitor showing required Spark Gap measurement



Flame Sensor - Refer to **FIGURE 22** and locate the flame sensor. Disconnect the wire; remove the screw and the flame sensor. Clean with an emery cloth.



Remove dirt and grease from the motor casing, the venter housing, and the venter wheel. Venter motor bearings are permanently lubricated. Follow these instructions for replacement of the venter motor and wheel assembly. Keep all hardware removed to be used in re-assembling and installing the replacement parts.

Replacement Instructions

1. Turn off the gas and disconnect the electric power.
2. Open the burner/control compartment access panel.
3. Disconnect the three venter motor wires at the DSI control, capacitor wires at the capacitor (if applicable), and ground screw (located on the control panel).
4. Sizes 30 and 45 - Disconnect the gas train and move it out of the way. Disconnect the gas supply at the union outside of the cabinet. At the gas valve, mark and disconnect the wires. Carefully remove the burner orifice and orifice adapter locking nut. Slide the orifice adapter out through the bracket on the burner pushing the gas train to the right. This will move the gas train out of the way.
5. Holding the venter motor, remove the three or four screws that attach the venter motor mounting plate to the venter housing. Remove the motor and wheel assembly from the heater.
6. Re-assemble with the replacement venter motor and wheel assembly. See **FIGURE 26**.

7. Follow the wiring diagram to connect the venter wires.
8. Sizes 30 and 45 - Reconnect the gas supply at the union outside of the cabinet. Leak test the connection with leak detecting solution.
9. Replace the access panel. Restore power to the heater and turn on the gas. Light, following the instructions on the lighting instruction plate. Check for proper operation.

Remove dirt and grease from the motor, blower, and guards. Check the belt for wear and proper tension.

The motor supplied has lifetime lubrication and sleeve bearings. If the motor has been replaced with one that has oil cups or grease fittings, lubricate the motor.

Check current draw to motor rating plate.

Carefully remove external dirt accumulation and check wiring connections.

WARNING

The operating valve is the prime safety shutoff. All gas supply lines must be free of dirt or scale before connecting to the unit to ensure positive closure.


The combination gas valve must be checked annually to ensure that the valve is shutting off gas flow completely.

Instructions:

- 1) Locate the 1/8" NPT pressure tap on the combination valve.

FIGURE 27 - Pressure Tap for Checking Gas Flow Shutoff

NOTE: Operational pressure settings and instructions for checking pressure settings are in Paragraph 6.1.



- 2) With the manual valve turned off to prevent flow to the gas valve, connect a manometer to the 1/8" outlet pressure tap in the valve. **NOTE:** A manometer (fluid-filled gauge) is recommended.
- 3) Turn the manual valve to the ON position and the heater OFF. Use your finger to fully block the main burner orifice for several seconds. Observe the manometer with the orifice blocked, and if any pressure is indicated, the gas valve is leaking. **A leaking gas valve must be replaced before the heater is put back in operation.**

10.2.8 Combustion Air Pressure Switch



See **FIGURE 22**, page 35, for location. (**NOTE:** Depending on date of manufacture and size, pressure switch may not be in the location indicated. Check the control bracket on the bottom of the compartment or further down on the compartment wall.) If it is determined that the pressure switch needs replacing, use only the factory-authorized replacement part that is designed for the model and size of heater being serviced.

NOTE: A unit operating above 6000 ft (1830M) elevation requires a high altitude pressure switch. See Paragraph 3.2.

10.2.9 Limit Control



If it is determined that the limit control needs replacing, use only a factory-authorized replacement part that is designed for the size of heater. For approximate limit location, see **FIGURE 22**, page 35.

10.2.10. Door Switch - UDBS only



If it is determined that the door switch needs replacing, use only a factory-authorized replacement part that is designed for the heater. For approximate switch location, see **FIGURE 22**, page 35.

10.2.11 Transformer



See **FIGURE 22**, page 35, for location. Use a voltmeter to verify that there are 24 volts output from the transformer. If the transformer is not functioning, it must be replaced. Use a replacement transformer identical to the factory-installed model.

10.2.12 Disconnect Switch - UDBS only



The disconnect switch is located in the sealed electrical box inside the control compartment with the toggle on the rear of the heater. If it is determined that the disconnect switch needs replacing, use only the factory-authorized replacement part that is designed for the heater. Always replace electrical box cover.

10.2.13 Vent or Vent/Combustion Air System

Check the complete system at least once a year. Inspection should include all joints, seams, concentric adapter box (UDBS), inlet air guard or inlet air cap (UDBS), and the vent terminal cap. Clean openings. Replace any defective parts.

10.0 Maintenance and Service (cont'd)

10.3 Troubleshooting

Check the Lights on the DSI Integrated Control Module (Circuit Board)

The integrated circuit board monitors the operation of the heater and includes two LED signal lights that indicate normal operation and various abnormal conditions. If the heater fails to operate properly, check this signal to determine the cause and/or to eliminate certain causes. LED is visible through viewport on Model UDBS. Remove access panel on Model UDBP. See operating sequence in Paragraph 9.

Do not attempt to repair the DSI integrated control module (circuit board); the only field replaceable component is the fuse.

IMPORTANT: When using a multimeter to troubleshoot the 24 volt circuit, place the meter's test leads into the 5 or 9 pin connectors located on the ignition control. Do not remove connectors or terminals from the electrical components. Doing so can result in misinterpreted readings due to the ignition control board's fault mode monitoring circuits.

Control Status - Green LED Codes

Steady ON Normal Operation, No call for heat

Fast Flash..Normal Operation, Call for heat

1 Flash.....System Lockout, Failed to detect or sustain flame

2 Flashes..Pressure Switch Did Not Close within 30 Seconds of Venter Motor

3 Flashes..High Limit or Flame Rollout Switch Open

4 Flashes....Pressure Switch is Closed Before Venter Motor is Energized

Steady OFF Blown fuse, No Power, or Defective Board


Flame Status - Yellow LED Codes

Steady ON..Flame is sensed

Slow Flash..Weak flame (current below 1.0 microamps \pm 50%)

Fast Flash...Undesired Flame (valve open and no call for heat)

DSI Integrated Control Module (Circuit Board) Trial Troubleshooting Flowchart



General Troubleshooting

| PROBLEM | PROBABLE CAUSE | REMEDY |
|--|---|---|
| Venter motor will not start | 1. No power to unit. | 1. Turn on power; check supply fuses or main circuit breaker. Turn on built-in control switch (Model UDBS only); replace switch if not operating. |
| | 2. No 24 volt power to integrated circuit board. | 2. Turn up thermostat; check control transformer output. |
| | 3. Integrated circuit board fuse blown. | 3. Correct cause. Replace fuse (type ATC or ATO, 32VDC, 3A). |
| | 4. No power to venter motor. | 4. Tighten connections at circuit board and/or motor terminals. |
| | 5. Integrated circuit board defective. | 5. Replace integrated circuit board. |
| | 6. Defective venter motor. | 6. Replace venter motor. See Paragraph 10.2.5. |
| Burner will not light | 1. Manual valve not open. | 1. Open manual valve. |
| | 2. Air in the gas line. | 2. Bleed gas line (initial startup only). |
| | 3. Gas pressure too high or too low. | 3. Supply pressure should be 5-14" w.c. for natural gas or 11-14" w.c. for propane. |
| | 4. No Spark: a) Loose wire connections. b) Transformer failure. c) Incorrect spark gap. d) Spark cable shorted to ground. e) Spark electrode shorted to ground. f) Burner not grounded. g) Circuit board not grounded. h) Unit not properly grounded. | 4. a) Be certain all wire connections are solid. b) Be sure 24 volts is available. c) Maintain spark gap at 1/8". d) Replace worn or grounded spark cable. e) Replace if ceramic spark electrode is cracked or grounded. f) Make certain integrated circuit board is grounded (Terminal P1-9). g) Make certain integrated circuit board is grounded to furnace chassis. h) Make certain unit is properly field grounded to earth ground and properly phased (L1 to hot lead L2 to neutral). |
| | i) Integrated circuit board fuse blown. j) Faulty integrated circuit board. | i) Correct cause. Replace fuse (type ATC or ATO, 32VDC, 3A). j) If 24 volt is available to the integrated circuit board and all other causes have been eliminated, replace board. |
| | 5. Lockout device interrupting control circuit by above causes. | 5. Reset lockout by interrupting control at the thermostat or main power. |
| | 6. Interlock door switch open (UDBS only). | 6. Close access door or replace switch. |
| | 7. Combustion air proving switch not closing | 7. a) Make sure unit is properly vented. b) Remove obstructions from vent. c) Replace faulty tubing to pressure switch. |
| | 8. Faulty combustion air proving switch. | 8. Replace combustion air proving switch. |
| | 9. Main valve not operating. a) Defective valve. b) Loose wire connections | 9. a) If 24 volt is measured at the valve connections and valve remains closed, replace valve. b) Check and tighten all wiring connections. |
| | 10. Integrated circuit board does not power valve. a) Loose wire connections. b) Flame sensor grounded. c) Incorrect gas pressure. d) Cracked ceramic at sensor. | 10. a) Check and tighten all wiring connections. b) Be certain flame sensor lead is not grounded or insulation or ceramic is not cracked. Replace as required. c) Supply pressure should be 5-14" w.c. for natural gas or 11-14" w.c. for propane. d) Replace sensor. |
| Burner cycles on and off | 1. Gas pressure too high or too low. | 1. Supply pressure should be 5-14" w.c. for natural gas or 11-14" w.c. for propane. |
| | 2. Burner not grounded | 2. Make certain integrated circuit board is grounded (Terminal P1-9). |
| | 3. Circuit board not grounded. | 3. Make certain integrated circuit board is grounded to furnace chassis. |
| | 4. Faulty integrated circuit board | 4. If 24 volt is available to the integrated circuit board and all other causes have been eliminated, replace board. |
| | 5. Combustion air proving switch not closing. | 5. a) Make sure unit is properly vented. b) Remove obstructions from vent. c) Replace faulty tubing to pressure switch. |
| | 6. Faulty combustion air proving switch. | 6. Replace combustion air proving switch. |
| | 7. Flame sensor grounded. | 7. Be certain flame sensor lead is not grounded or insulation or ceramic is not cracked. Replace as required. |
| | 8. Cracked ceramic at sensor. | 8. Replace sensor. |
| | 9. Incorrect polarity. | 9. Reverse line volt leads to integrated circuit board. |
| | 10. Pin terminal loose at 9-pin plug. | 10. Replace wire harness. |
| No heat (Heater Operating) | 1. Incorrect valve outlet pressure or orifice. | 1. Check valve outlet pressure. See Rating plate for manifold pressure. |
| | 2. Cycling on limit control. | 2. Check air throughput. |
| | 3. Improper thermostat location or adjustment. | 3. See thermostat manufacturer's instructions. |
| Blower motor or venter motor will not run | 1. Circuit open. | 1. Check wiring and connections. |
| | 2. Defective integrated circuit board. | 2. Replace board. |
| | 3. Defective motor or starter. | 3. Replace motor or starter. |
| Blower or venter motor turns on and off while burner is operating | 1. Motor overload device cycling on and off. | 1. Check motor load against motor rating plate. Replace motor if needed. |
| Blower motor or venter motor cuts out on overload | 1. Low or high voltage supply. | 1. Correct electric supply. |
| | 2. Defective motor. | 2. Replace motor. |
| | 3. Poor air flow. | 3. Clean motor, blower, blower guard, filter, and coils. |
| | 4. Defective bearing or lubrication. | 4. Lubricate bearings (motor permitting) or replace motor. |
| Blower motor cuts out on overload | 1. Improper motor pulley and/or adjustment. | 1. See instructions in Paragraph 6.4.2. |
| | 2. Improper static pressure in the duct system. | 2. Adjust duct system dampers. |
| | 3. Low voltage. | 3. Check power supply. |

APPENDIX

| TECHNICAL DATA - Sizes 30 - 125 (Data applies to both Models UDBP and UDBS unless noted otherwise.) | | | | | | | | |
|---|---|-----------|--------|--------|--------|--------|---------|---------|
| Size | | | 30 | 45 | 60 | 75 | 100 | 125 |
| Input Heating Capacity | | BTUH | 30,000 | 45,000 | 60,000 | 75,000 | 105,000 | 120,000 |
| | | kw/h | 8.8 | 13.2 | 17.6 | 22.0 | 30.8 | 35.2 |
| Thermal Efficiency (%) | | | 82 | 82 | 82 | 82 | 83 | 83 |
| Output Heating Capacity ^A | | BTUH | 24,600 | 36,900 | 49,200 | 61,500 | 87,150 | 99,600 |
| | | kw/h | 7.2 | 10.8 | 14.4 | 18.0 | 25.6 | 29.2 |
| Gas Connection (inches) ^B | | Natural | 1/2 | 1/2 | 1/2 | 1/2 | 1/2 | 1/2 |
| | | Propane | 1/2 | 1/2 | 1/2 | 1/2 | 1/2 | 1/2 |
| Vent Connection Size ^C (inches diameter) | | | 4 | 4 | 4 | 4 | 4 | 4 |
| Control Amps (24 volt) | | | 1.0 | 1.0 | 1.0 | 1.0 | 1.0 | 1.0 |
| Full Load Amps (with standard HP 115V motor) | | | 3.7 | 3.7 | 7.1 | 7.1 | 13.0 | 13.0 |
| Maximum Over Current Protection (115V) ^D | | | 15 | 15 | 15 | 15 | 30 | 30 |
| Normal Power Consumption (watts @ full load, medium speed) | | | 215 | 215 | 447 | 447 | 537 | 537 |
| Minimum Discharge Air Temperature Rise | See Paragraph 2.2 for sound data based on blower speed. | °F | 45 | 45 | 45 | 45 | 45 | 45 |
| | | °C | 25 | 25 | 25 | 25 | 25 | 25 |
| Maximum Discharge Air Temperature Rise | | °F | 75 | 75 | 75 | 75 | 75 | 75 |
| | | °C | 41.7 | 41.7 | 41.7 | 41.7 | 41.7 | 41.7 |
| Maximum Air Volume | | CFM | 506 | 759 | 1012 | 1265 | 1793 | 2049 |
| | | M³/minute | 14.3 | 21.5 | 28.7 | 35.8 | 50.8 | 58.0 |
| Minimum Air Volume | | CFM | 304 | 456 | 607 | 759 | 1076 | 1230 |
| | | M³/minute | 8.6 | 12.9 | 17.2 | 21.5 | 30.5 | 34.8 |
| Discharge Air Opening Area | | FT² | 0.1 | 0.1 | 1.3 | 1.3 | 2.0 | 2.0 |
| | | M² | 0.1 | 0.1 | 0.1 | 0.1 | 0.2 | 0.2 |
| Maximum Output Velocity | | FPM | 527 | 791 | 810 | 1012 | 892 | 1020 |
| | | M/minute | 159 | 239 | 239 | 299 | 267 | 305 |
| Minimum Output Velocity | | FPM | 316 | 475 | 486 | 607 | 535 | 612 |
| | | M/minute | 96 | 143 | 143 | 179 | 160 | 183 |
| Standard Blower Motor HP | | | 1/6 | 1/6 | 1/3 | 1/3 | 3/4 | 3/4 |
| Blower Size | | inches | 9 X 6 | 9 X 6 | 9 X 6 | 9 X 6 | 10 X 10 | 10 X 10 |

| TECHNICAL DATA - Sizes 150 - 400 (Data applies to both Models UDBP and UDBS unless noted otherwise.) | | | | | | | | | |
|--|---|---------|---------|---------|---------|---------|---------|---------|---------|
| Size | | 150 | 175 | 200 | 225 | 250 | 300 | 350 | 400 |
| Input Heating Capacity | BTUH | 150,000 | 175,000 | 200,000 | 225,000 | 250,000 | 300,000 | 350,000 | 400,000 |
| | kw/h | 43.9 | 51.2 | 58.6 | 65.9 | 73.2 | 87.8 | 102.5 | 117.1 |
| Thermal Efficiency (%) | | 83 | 83 | 83 | 83 | 83 | 83 | 83 | 82 |
| Output Heating Capacity ^A | BTUH | 124,500 | 145,250 | 166,000 | 186,750 | 207,500 | 249,000 | 290,500 | 328,000 |
| | kw/h | 36.4 | 42.5 | 48.6 | 54.7 | 60.8 | 72.9 | 85.1 | 96.0 |
| Gas Connection (inches) ^B | Natural | 1/2 | 1/2 | 1/2 | 3/4 | 3/4 | 3/4 | 3/4 | 3/4 |
| | Propane | 1/2 | 1/2 | 1/2 | 3/4 | 3/4 | 3/4 | 3/4 | 3/4 |
| Vent Connection Size ^C (inches diameter) | | 5 | 5 | 5 | 5 | 5 | 6 | 6 | 6 |
| Control Amps (24 volt) | | 1.0 | 1.0 | 1.0 | 1.0 | 1.0 | 1.0 | 1.0 | 1.0 |
| Full Load Amps (w/std HP 115V motor) | | 5.9 | 9.6 | 10.5 | 12.7 | 12.7 | 17.7 | 27.3 | 27.3 |
| Maximum Over Current Protection (115V) ^D | | 15 | 20 | 25 | 30 | 30 | 40 | 60 | 60 |
| Normal Power Consumption (watts) | | 230 | 415 | 485 | 675 | 675 | 1260 | 1635 | 1635 |
| Minimum Discharge Air Temperature Rise | See Paragraph 2.2 for sound data based on temperature rise. | °F | 45 | 45 | 45 | 45 | 45 | 45 | 50 |
| | | °C | 25 | 25 | 25 | 25 | 25 | 25 | 27.8 |
| Maximum Discharge Air Temperature Rise | | °F | 75 | 75 | 75 | 75 | 75 | 75 | 80 |
| | | °C | 41.7 | 41.7 | 41.7 | 41.7 | 41.7 | 41.7 | 44.4 |
| Maximum Air Volume | CFM | 2562 | 2989 | 3416 | 3843 | 4270 | 5123 | 5977 | 6185 |
| | M ³ /minute | 72.5 | 84.6 | 96.7 | 108.8 | 120.9 | 145.1 | 169.2 | 175.1 |
| Minimum Air Volume | CFM | 1537 | 1793 | 2049 | 2306 | 2562 | 3074 | 3586 | 4100 |
| | M ³ /minute | 43.5 | 50.8 | 58.0 | 65.3 | 72.5 | 87.0 | 101.5 | 116.1 |
| Discharge Air Opening Area | Ft ² | 2.6 | 2.6 | 2.6 | 3.5 | 3.5 | 4.8 | 4.8 | 4.8 |
| | M ² | 0.2 | 0.2 | 0.2 | 0.3 | 0.3 | 0.5 | 0.5 | 0.5 |
| Maximum Output Velocity | FPM | 1001 | 1168 | 1334 | 1095 | 1217 | 1070 | 1248 | 1291 |
| | M/minute | 305 | 356 | 407 | 334 | 371 | 326 | 380 | 393 |
| Minimum Output Velocity | FPM | 600 | 700 | 800 | 657 | 730 | 642 | 749 | 856 |
| | M/minute | 183 | 213 | 244 | 200 | 223 | 196 | 228 | 261 |
| Standard Open 115V Blower Motor HP | | 1/4 | 1/2 | 1/2 | 3/4 | 3/4 | 1-1/2 | 2 | 2 |
| Blower Size | | inches | 12 x 12 | 12 x 12 | 12 x 12 | 15 x 11 | 15 x 11 | 15 x 15 | 15 x 15 |

^A CSA ratings for altitudes to 2000 ft.

^B Size shown is for gas connection to a single-stage gas valve, not supply line size.

^C Smaller and/or larger vent pipe diameters may be permissible; refer to the Venting Installation Manual for Power Vented Units.

^D MOPD = 2.25 x (largest motor (FLA) + smallest motor FLA). Answer is rounded to the nearest commercially available circuit breaker.

INDEX

A

Abnormal Heat Cycle Functions 30
Adjusting Blower Speed 18
Aircraft Hangars 3
APPENDIX 42

B

Belt 18
Belt Drive 19
Belt Guard in Option AZ6 and CD10 20
Blower 18
Blower Guard in Options AZ6, AZ7,
CD10, and CD12 20
Clean the Burner 36
Burner Maintenance 36
Burner Orifice 37
Burner Removal 36

C

California Warning Label 3
Certification 2
Checking Gas Flow Shutoff 39
Check installation after startup 33
Check the installation prior to startup
32
Check the Lights 40
Chlorine 6
Circuit Board (DSI Integrated Control
Module) 21
Clearances 8
LED Codes 29, 40
Combustion Air 16, 17
Combustion Air Pressure Switch 39
Combustion Air Proving (Pressure)
Switch 26
Commissioning 32
Confined Space 16
Contact 44
Continuous Blower Operation 31
Control Wiring 21

D

DDC Controls 28
Dimensions 9
Direct Drive 19
Disconnect Switch 39
Door Switch 39
Door Switch - Model UDBS only 26
Downturn Nozzle Kits 8
Drive 18
DSI Integrated Control Module 29, 37,
40
Duct Flange 17

E

Electrical Supply 20

F

Continuous Fan Operation 31
Fan/Blower Off Delay 30
Fan/Blower On Delay 29
Fault Modes 31
Flame Sensor 38
fuse 37

G

Garages 3

Gas Connection Size 13
Gas Conversion Kits 13
Gas Supply 12
Gas Supply Line 13
Gas Valve 27, 38
Gas Valve ON/OFF Control Knob 33
Gas Valve Relay Fault 31
Guards 20

H

Hanging the Heater 11, 12
Hard Lockout 31
HAZARD INTENSITY LEVELS 2
Hazard Labels and Notices 2
Lower Portion of the Heat Exchanger
37
Heat Exchanger Maintenance 35
High Altitude Capacity 15
High Altitude Derate 14
High Altitude Kit 7, 8

I

Ignition System 29, 37, 38
Ignition Trial 29
Ignitor 37
Installation Codes 3

L

Leak-test 12
Lifting 11
LED lights 29
Limit Control 26, 39
Limit Switch 30
Literature Bag 34
Location 6
Unit Heater Location 4
Location of Controls 35
Lockout 31
optional vertical louvers 7

M

Maintenance Procedures 35
Maintenance Schedule 34
Massachusetts Requirement 3
Blower Motor 27
Motor 38
Venter Motor 38
Multiple Heater Control 27

N

Normal Heat Cycle 29, 30

O

Operation 32
Option AX4 17
Option CC1 7
Option CC2 or CC6 3, 7
Option CD 2, 3, or 4 8
Option CL31 27
Option CL32 27
Option CM3 27
Option DJ20 or DJ21 7
Options D10 and D14 28
Orifice Pressure 13

P

Polytube Adapter 17
Post Purge 30
Power Interruption 31
Preparing for Installation 7

Prepurge 29
Pressure Switch 30
Pressure Switch Settings 26
PRESSURE TESTING SUPPLY PIPING
12

S

Mounting the Sensor 28
Soft Lockout 31
Sound Data 5
Spark Gap 38
Startup 32
stepdown transformer 7
stepdown transformer, Option CG2 or
CG4 20
Supply Wiring 20
Suspending 11
Suspending the Heater with Threaded
Rods 11
suspension points 9, 10
Swivel Connectors 12

T

TECHNICAL DATA 42
Terminal Strip for 24-volt 21
Thermostat 27
Unit Mounted Thermostat 27
Throw 4
Transformer 39
500VA Stepdown Transformer 20
Troubleshooting 40, 41
Troubleshooting Flowchart 40
TURN OFF GAS 33

U

Uncrating and Inspecting 6
Undesired Flame 31

V

Valve Outlet Pressure 14
Valve Outlet Pressure Settings by
Elevation 14
Vent 39
Vent/Combustion Air 39
Vent/Combustion Air Kit 3, 7
vent cap 7
Venter Motor 27
Venter Wheel 38
Venting Manual 3, 6
Vent System Testing Procedure 33
460 or 575 supply voltage 20

W

Warranty 3
Weights 11
WHAT TO DO IF YOU SMELL GAS 32
Wiring Connections 21
Wiring Diagram for Model UDBP or
UDBS, Sizes 150-400, Single Stage
24
Wiring Diagram for Model UDBP or
UDBS, Sizes 150-400, Two Stage 25
Wiring Diagram for Model UDBP or
UDBS, Sizes 30-125, Two Stage 23
Wiring Diagram for Model UDBP or
UDBS Sizes 30-125, Single Stage 22
Wiring Diagrams 22

INSTALLATION RECORD - To be completed by the installer:

Installer:

Name _____
Company _____
Address _____

Phone _____

Distributor (company from which the unit was purchased):

Company _____
Contact _____
Address _____

Phone _____

Model _____ Serial No. _____ Date of Installation _____

SPECIFIC INSTALLATION NOTES: (i.e. Location, Amps, Gas Pressure, Temperature, Voltage, Adjustments, Warranty, etc.)

BUILDING OWNER OR MAINTENANCE PERSONNEL:

For service or repair

- Contact the installer listed above.
- If you need additional assistance, contact the Reznor® Distributor listed above.
- For more information, contact your Reznor® Representative by calling 1-800-695-1901.

Reznor
150 McKinley Avenue
Mercer, PA 16137

www.ReznorHVAC.com; (800) 695-1901

©2018 Reznor LLC, All rights reserved.

Trademark Notes: Reznor®, TCore2®, and V3® are registered in at least the United States.

All other trademarks are the property of their respective owners.

Form I-UDB (03-18) PN202658R16

REZNOR®