

## Vent Extension Field Kit

Applies to: **Models RDCB, RDCC,  
RDDB and RDDC**

### Application

The standard MAPS unit with gas-fired heat section vents combustion gas horizontally. The vent extension kit provides for attaching a vertical vent pipe that will allow the vent terminal to extend above the unit.


### Components

Vent Extension Kit, P/N 221120

Qty	Description	P/N
1	Vent Collar Adapter	221108
1	Vent Support	221104
1	Vent Pipe Retainer Band	221103


In addition, the following **must be field supplied:**

- 6" diameter, 26 gauge flue pipe (see illustration)
- 6" diameter Reznor Vent Cap, **P/N 111850** (or equivalent)
- Sheetmetal screws



**Vent Collar Adapter**


- Attach the vent collar adapter to the vent opening on the side of the cabinet.



**Vent Pipe Support**

Use the specially designed vent pipe support and retainer to support the vertical vent pipe. Attach the support to the top of the unit with sheetmetal screws.

### Installation Requirements



\*See cross-reference by cabinet size and model size on page 2.

## Cross-Reference for RDCB, RECC, RDDB and RDDC Model Size and Gas Heat Section to Cabinet Size B, and C

Model RDCB	Model RDCC	Gas Heat Section Size							
		-250	-300	-400	-500	-600	-700	-800	-1000
<b>060</b>	--	--	--	--	--	--	--	--	--
<b>078</b>	--	B	B	B*	--	--	--	--	--
<b>090</b>		B	B	B*	--	--	--	--	--
<b>118</b>	<b>120</b>	B	B	B*	--	--	--	--	--
<b>136</b>	--	B	B	B*	--	--	--	--	--
<b>160</b>		B	B	B*	--	--	--	--	--
<b>186</b>	--	B	B	B*	--	--	--	--	--
<b>200</b>		B	B	B*	--	--	--	--	--
<b>190</b>	--	--	C	C	C	C	--	C**	
<b>216</b>	--	--	C	C	C	C	--	C**	
<b>298</b>		--	--	C	C	C	--	C**	
<b>410</b>		--	--	C	C	C	--	C**	
Model RDDB	Model RDDC	Gas Heat Section Size							
		-250	-300	-400	-500	-600	-700	-800	-1000
<b>084</b>	--	--	--	--	--	--	--	--	--
<b>102</b>	--	B	B	--	--	--	--	--	--
<b>114</b>		B	B	--	--	--	--	--	--
<b>142</b>	<b>144</b>	B	B	--	--	--	--	--	--
<b>162</b>	--	B	B	--	--	--	--	--	--
<b>184</b>		B	B	--	--	--	--	--	--
--	<b>196</b>	B	B	--	--	--	--	--	--
<b>210</b>	--	B	B	--	--	--	--	--	--
<b>222</b>	--	B	B	--	--	--	--	--	--
<b>224</b>	--	B	B	--	--	--	--	--	--
<b>236</b>		B	B	--	--	--	--	--	--
--	<b>257</b>	B	B	--	--	--	--	--	--
<b>248</b>		--	--	C	C	C	--	C**	
<b>262</b>		--	--	C	C	C	--	C**	
<b>272</b>	--	--	--	C	C	C	--	C**	
<b>288</b>	--	--	--	C	C	C	--	C**	
<b>354</b>		--	--	C	C	C	--	C**	
<b>370</b>		--	--	C	C	C	--	C**	
<b>468</b>		--	--	C	C	C	--	C**	
<b>482</b>		--	--	C	C	C	--	C**	

\* A MAPS® B Cabinet with 500 mbh of gas heat is a Size 250 mbh heat section plus an Option JH25 curb with a 250 mbh duct furnace.

\*\* A MAPS® C Cabinet with 1000 mbh of gas heat is a Size 700 mbh heat section plus an Option JH30 curb with a 300 mbh duct furnace.



Form CP-MAPS-Vnt Ext, P/N 221109R1, Page 2

[www.ReznorHVAC.com](http://www.ReznorHVAC.com); (800) 695-1901

©2015 Reznor LLC, All rights reserved.

**Trademark Note:** Reznor® and MAPS® are registered in at least the United States. All other trademarks are the property of their respective owners.

05/15 Form CP-MAPS-Vnt Ext (05-15)